

# **EG06xK&Ex120K&EM060K** **Series Power Back-off** **Application Note**

**LTE-A Module Series**

Version: 1.0.0

Date: 2021-12-16

Status: Preliminary



At Quectel, our aim is to provide timely and comprehensive services to our customers. If you require any assistance, please contact our headquarters:

**Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: [info@quectel.com](mailto:info@quectel.com)

**Or our local offices. For more information, please visit:**

<http://www.quectel.com/support/sales.htm>.

**For technical support, or to report documentation errors, please visit:**

<http://www.quectel.com/support/technical.htm>.

Or email us at: [support@quectel.com](mailto:support@quectel.com).

## Legal Notices

We offer information as a service to you. The provided information is based on your requirements and we make every effort to ensure its quality. You agree that you are responsible for using independent analysis and evaluation in designing intended products, and we provide reference designs for illustrative purposes only. Before using any hardware, software or service guided by this document, please read this notice carefully. Even though we employ commercially reasonable efforts to provide the best possible experience, you hereby acknowledge and agree that this document and related services hereunder are provided to you on an “as available” basis. We may revise or restate this document from time to time at our sole discretion without any prior notice to you.

## Use and Disclosure Restrictions

### License Agreements

Documents and information provided by us shall be kept confidential, unless specific permission is granted. They shall not be accessed or used for any purpose except as expressly provided herein.

### Copyright

Our and third-party products hereunder may contain copyrighted material. Such copyrighted material shall not be copied, reproduced, distributed, merged, published, translated, or modified without prior written consent. We and the third party have exclusive rights over copyrighted material. No license shall be granted or conveyed under any patents, copyrights, trademarks, or service mark rights. To avoid ambiguities, purchasing in any form cannot be deemed as granting a license other than the normal non-exclusive, royalty-free license to use the material. We reserve the right to take legal action for noncompliance with abovementioned requirements, unauthorized use, or other illegal or malicious use of the material.

## Trademarks

Except as otherwise set forth herein, nothing in this document shall be construed as conferring any rights to use any trademark, trade name or name, abbreviation, or counterfeit product thereof owned by Quectel or any third party in advertising, publicity, or other aspects.

## Third-Party Rights

This document may refer to hardware, software and/or documentation owned by one or more third parties (“third-party materials”). Use of such third-party materials shall be governed by all restrictions and obligations applicable thereto.

We make no warranty or representation, either express or implied, regarding the third-party materials, including but not limited to any implied or statutory, warranties of merchantability or fitness for a particular purpose, quiet enjoyment, system integration, information accuracy, and non-infringement of any third-party intellectual property rights with regard to the licensed technology or use thereof. Nothing herein constitutes a representation or warranty by us to either develop, enhance, modify, distribute, market, sell, offer for sale, or otherwise maintain production of any our products or any other hardware, software, device, tool, information, or product. We moreover disclaim any and all warranties arising from the course of dealing or usage of trade.

## Disclaimer

- a) We acknowledge no liability for any injury or damage arising from the reliance upon the information.
- b) We shall bear no liability resulting from any inaccuracies or omissions, or from the use of the information contained herein.
- c) While we have made every effort to ensure that the functions and features under development are free from errors, it is possible that they could contain errors, inaccuracies, and omissions. Unless otherwise provided by valid agreement, we make no warranties of any kind, either implied or express, and exclude all liability for any loss or damage suffered in connection with the use of features and functions under development, to the maximum extent permitted by law, regardless of whether such loss or damage may have been foreseeable.
- d) We are not responsible for the accessibility, safety, accuracy, availability, legality, or completeness of information, advertising, commercial offers, products, services, and materials on third-party websites and third-party resources.

**Copyright © Quectel Wireless Solutions Co., Ltd. 2021. All rights reserved.**

# About the Document

## Revision History

Version	Date	Author	Description
-	2021-12-16	Kevin LI	Creation of the document
1.0.0	2021-12-16	Kevin LI	Preliminary

## Contents

About the Document .....	3
Contents .....	4
Table Index .....	5
<b>1 Introduction .....</b>	<b>6</b>
<b>2 Description of AT Commands .....</b>	<b>7</b>
2.1. AT Command Introduction .....	7
2.1.1. Definitions .....	7
2.1.2. AT Command Syntax .....	7
2.2. Declaration of AT Command Examples .....	8
2.3. Usage for Power Back-off AT Commands .....	8
2.4. Description of Power Back-off AT Commands .....	8
2.4.1. AT+QSAR Set SAR Power Back-off Level for WCDMA/LTE .....	8
2.4.2. AT+QCFG="sar_dsi" Set SAR Power Back-off Value for WCDMA/LTE .....	10
<b>3 Appendix References .....</b>	<b>14</b>

## Table Index

Table 1: Types of AT Commands .....	7
Table 2: SAR Power Back-off Level and Value .....	9
Table 3: Terms and Abbreviations.....	14

# 1 Introduction

This document mainly introduces how to implement the power back-off function of EG06Xk, Ex120K and EM060K series modules under the corresponding WCDMA/LTE networks through AT commands.

# 2 Description of AT Commands

## 2.1. AT Command Introduction

### 2.1.1. Definitions

- **<CR>** Carriage return character.
- **<LF>** Line feed character.
- **<...>** Parameter name. Angle brackets do not appear on the command line.
- **[...]** Optional parameter of a command or an optional part of TA information response. Square brackets do not appear on the command line. When an optional parameter is not given in a command, the new value equals to its previous value or the default settings, unless otherwise specified.
- **Underline** Default setting of a parameter.

### 2.1.2. AT Command Syntax

All command lines must start with **AT** or **at** and end with **<CR>**. Information responses and result codes always start and end with a carriage return character and a line feed character: **<CR><LF><response><CR><LF>**. In tables presenting commands and responses throughout this document, only the commands and responses are presented, and **<CR>** and **<LF>** are deliberately omitted.

**Table 1: Types of AT Commands**

Command Type	Syntax	Description
Test Command	<b>AT+&lt;cmd&gt;=?</b>	Test the existence of corresponding Write Command and return information about the type, value, or range of its parameter.
Read Command	<b>AT+&lt;cmd&gt;?</b>	Check the current parameter value of a corresponding Write Command.
Write Command	<b>AT+&lt;cmd&gt;=&lt;p1&gt;[,&lt;p2&gt;[,&lt;p3&gt;[...]]]</b>	Set user-definable parameter value.
Execution Command	<b>AT+&lt;cmd&gt;</b>	Return a specific information parameter or perform a specific action.

## 2.2. Declaration of AT Command Examples

The AT command examples in this document are provided to help you learn about how to use the AT commands introduced herein. The examples, however, should not be taken as Quectel's recommendation or suggestions about how you should design a program flow or what status you should set the module into. Sometimes multiple examples may be provided for one AT command. However, this does not mean that there exists a correlation among these examples and that they should be executed in a given sequence.

## 2.3. Usage for Power Back-off AT Commands

**Step 1:** Configure the SAR power back-off level and whether to save the configurations after power-off through **AT+QSAR=<level>,[<save>]**. The command takes effect immediately.

**Step 2:** Configure the SAR power back-off value of level 1-level 8 for WCDMA/LTE through **AT+QCFG="sar\_dsi"**. The default SAR power back-off value of level 1-level 8 for WCDMA/LTE is corresponding to 23-16 dBm. Please refer to **Table 3**.

## 2.4. Description of Power Back-off AT Commands

### 2.4.1. AT+QSAR Set SAR Power Back-off Level for WCDMA/LTE

This command sets SAR power back-off level for WCDMA/LTE.

<b>AT+QSAR Set SAR Power Back-off Level for WCDMA/LTE</b>	
Test Command <b>AT+QSAR=?</b>	Response <b>+QSAR:</b> (range of supported <level>s),(list of supported <save>s)  OK Or ERROR  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Read Command <b>AT+QSAR?</b>	Response <b>+QSAR: &lt;level&gt;</b>  OK

	Or <b>ERROR</b>  If the error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Write Command <b>AT+QSAR=&lt;level&gt;[,&lt;save&gt;]</b>	Response <b>OK</b> Or <b>ERROR</b>  If there is an error related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>
Maximum Response Time	500 ms
Characteristics	The command takes effect immediately. <b>&lt;save&gt;</b> determines whether the configurations will be saved after power-off.

**Parameter**

<b>&lt;level&gt;</b>	Integer type. SAR power back-off level for WCDMA/LTE. Range: 0–8. <u>0</u> Disable power back-off function 1–8      SAR power back-off level for WCDMA/LTE. The default maximum SAR power back-off value of level 1-level 8, please refer to <b>Table 3</b> . The maximum SAR power back-off value of level 1-level 8 can be configured through <b>AT+QCFG="sar_dsi"</b> , please refer to <b>Chapter 2.4.2</b> .
<b>&lt;save&gt;</b>	Integer type. Whether to save the configuration to NVM. If this parameter is omitted, the configuration will not be saved after power-off by default. <u>0</u> Not save 1      Save

**Table 2: SAR Power Back-off Level and Value**

Network	<level>	Sar <sub>level(n)</sub>
<b>WCDMA</b>	1	Default maximum SAR power back-off value: 23 dBm
	2	Default maximum SAR power back-off value: 22 dBm
	3	Default maximum SAR power back-off value: 21 dBm
	4	Default maximum SAR power back-off value: 20 dBm
	5	Default maximum SAR power back-off value: 19 dBm

LTE	6	Default maximum SAR power back-off value: 18 dBm
	7	Default maximum SAR power back-off value: 17 dBm
	8	Default maximum SAR power back-off value: 16 dBm
	1	Default maximum SAR power back-off value: 23 dBm
	2	Default maximum SAR power back-off value: 22 dBm
	3	Default maximum SAR power back-off value: 21 dBm
	4	Default maximum SAR power back-off value: 20 dBm
	5	Default maximum SAR power back-off value: 19 dBm
	6	Default maximum SAR power back-off value: 18 dBm
	7	Default maximum SAR power back-off value: 17 dBm
	8	Default maximum SAR power back-off value: 16 dBm

**Example**

```

AT+QSAR=?
+QSAR: (0-8),(0,1)

OK
AT+QSAR?
+QSAR: 0

OK
AT+QSAR=1
OK
    
```

**2.4.2. AT+QCFG="sar\_dsi" Set SAR Power Back-off Value for WCDMA/LTE**

This command queries and configures SAR power back-off value for WCDMA/LTE.

**AT+QSAR Set SAR Power Back-off Value for WCDMA/LTE**

Write Command	Response
<b>AT+QCFG="sar_dsi" [&lt;RAT&gt; [&lt;band &gt;,&lt;DSI1&gt;,&lt;DSI2&gt;,&lt;DSI3&gt;,&lt;DSI4&gt;,&lt;DSI5&gt;,&lt;DSI6&gt;,&lt;DSI7&gt;,&lt;DSI8&gt;]]</b>	If the optional parameters are omitted, query the SAR back-off parameters for all supported WCDMA/LTE bands: <b>+QCFG: "SAR_DSI",&lt;RAT&gt;,&lt;band1&gt;,&lt;DSI1&gt;,&lt;DSI2&gt;,&lt;DSI3&gt;,&lt;DSI4&gt;,&lt;DSI5&gt;,&lt;DSI6&gt;,&lt;DSI7&gt;,&lt;DSI8&gt;</b> ...

	<p><b>OK</b></p> <p>If &lt;band&gt;, &lt;DSI1&gt;, &lt;DSI2&gt;, &lt;DSI3&gt;, &lt;DSI4&gt;, &lt;DSI5&gt;, &lt;DSI6&gt;, &lt;DSI7&gt; and &lt;DSI8&gt; are omitted, query the SAR back-off value for current LTE/WCDMA bands:  <b>+QCFG: "SAR_DSI",&lt;RAT&gt;,&lt;band1&gt;,&lt;DSI1&gt;,&lt;DSI2&gt;,&lt;DSI3&gt;,&lt;DSI4&gt;,&lt;DSI5&gt;,&lt;DSI6&gt;,&lt;DSI7&gt;,&lt;DSI8&gt;</b>                  ...</p> <p><b>OK</b></p> <p>If the optional parameters are specified, set SAR power backoff value for LTE/WCDMA band:</p> <p><b>OK</b>                  Or  <b>ERROR</b></p>
Maximum Response Time	300 ms
Characteristics	The command takes effect after rebooting. The configurations will be saved automatically.

**Parameter**

<b>&lt;RAT&gt;</b>	String type. Radio Access Technology. "lte_wcdma" LTE and WCDMA "lte" LTE "wcdma" WCDMA (not supported currently)																										
<b>&lt;band&gt;</b>	Integer type. Supported LTE/WCDMA bands.																										
<b>&lt;band1&gt;</b>	String type. The supported LTE/WCDMA bands corresponding to <band>. <b>WCDMA (not supported currently):</b> <table border="0" style="width: 100%;"> <tr> <td style="text-align: left;"><b>&lt;band&gt;</b></td> <td style="text-align: left;"><b>&lt;band1&gt;</b></td> </tr> <tr> <td>1</td> <td>WCDMA B1</td> </tr> <tr> <td>2</td> <td>WCDMA B2</td> </tr> <tr> <td>3</td> <td>WCDMA B3</td> </tr> <tr> <td>4</td> <td>WCDMA B4</td> </tr> <tr> <td>5</td> <td>WCDMA B5</td> </tr> <tr> <td>8</td> <td>WCDMA B8</td> </tr> <tr> <td>9</td> <td>WCDMA B9</td> </tr> <tr> <td>11</td> <td>WCDMA B11</td> </tr> <tr> <td>19</td> <td>WCDMA B19</td> </tr> </table> <b>LTE:</b> <table border="0" style="width: 100%;"> <tr> <td style="text-align: left;"><b>&lt;band&gt;</b></td> <td style="text-align: left;"><b>&lt;band1&gt;</b></td> </tr> <tr> <td>1</td> <td>LTE B1</td> </tr> <tr> <td>2</td> <td>LTE B2</td> </tr> </table>	<b>&lt;band&gt;</b>	<b>&lt;band1&gt;</b>	1	WCDMA B1	2	WCDMA B2	3	WCDMA B3	4	WCDMA B4	5	WCDMA B5	8	WCDMA B8	9	WCDMA B9	11	WCDMA B11	19	WCDMA B19	<b>&lt;band&gt;</b>	<b>&lt;band1&gt;</b>	1	LTE B1	2	LTE B2
<b>&lt;band&gt;</b>	<b>&lt;band1&gt;</b>																										
1	WCDMA B1																										
2	WCDMA B2																										
3	WCDMA B3																										
4	WCDMA B4																										
5	WCDMA B5																										
8	WCDMA B8																										
9	WCDMA B9																										
11	WCDMA B11																										
19	WCDMA B19																										
<b>&lt;band&gt;</b>	<b>&lt;band1&gt;</b>																										
1	LTE B1																										
2	LTE B2																										

---

3	LTE B3
4	LTE B4
5	LTE B5
6	LTE B6
7	LTE B7
8	LTE B8
9	LTE B9
10	LTE B10
11	LTE B11
12	LTE B12
13	LTE B13
14	LTE B14
17	LTE B17
18	LTE B18
19	LTE B19
20	LTE B20
21	LTE B21
23	LTE B23
25	LTE B25
26	LTE B26
27	LTE B27
28	LTE B28
30	LTE B30
34	LTE B34
38	LTE B38
39	LTE B39
40	LTE B40
41	LTE B41
42	LTE B42
43	LTE B43
46	LTE B46
47	LTE B47
48	LTE B48
66	LTE B66
71	LTE B71
250	LTE B250

**<DSI1>** Integer type. SAR back-off value corresponding to DSI1 (device status index number 1). The value should be set as a multiple of 10. Range: 60–300. Default value: 230.  
Unit: 0.1 dBm.

**<DSI2>** Integer type. SAR back-off value corresponding to DSI2 (device status index number 2). The value should be set as a multiple of 10. Range: 60–300. Default value: 220.  
Unit: 0.1 dBm.

**<DSI3>** Integer type. SAR back-off value corresponding to DSI3 (device status index number 3). The value should be set as a multiple of 10. Range: 60–300. Default value: 210.

---

	Unit: 0.1 dBm.
<DSI4>	Integer type. SAR back-off value corresponding to DSI4 (device status index number 4). The value should be set as a multiple of 10. Range: 60–300. Default value: 200. Unit: 0.1 dBm.
<DSI5>	Integer type. SAR back-off value corresponding to DSI5 (device status index number 5). The value should be set as a multiple of 10. Range: 60–300. Default value: 190. Unit: 0.1 dBm.
<DSI6>	Integer type. SAR back-off value corresponding to DSI6 (device status index number 6). The value should be set as a multiple of 10. Range: 60–300. Default value: 180. Unit: 0.1 dBm.
<DSI7>	Integer type. SAR back-off value corresponding to DSI7 (device status index number 7). The value should be set as a multiple of 10. Range: 60–300. Default value: 170. Unit: 0.1 dBm.
<DSI8>	Integer type. SAR back-off value corresponding to DSI8 (device status index number 8). The value should be set as a multiple of 10. Range: 60–300. Default value: 160. Unit: 0.1 dBm.

**Example**

```

AT+QCFG="sar_dsi"
+QCFG: "SAR_DSI",<RAT>,<band1>,<DSI1>,<DSI2>,<DSI3>,<DSI4>,<DSI5>,<DSI6>,<DSI7>,<DSI8>

OK
AT+QCFG="sar_dsi","lte_wcdma"
+QCFG: "sar_dsi","lte_wcdma",LTE B2,230,220,210,200,190,180,170,160
...

OK
AT+QCFG="sar_dsi","lte",1,200,180,230,230,230,230,230,230

OK
    
```

# 3 Appendix References

**Table 3: Terms and Abbreviations**

Abbreviation	Description
DSI	Device State Index
LTE	Long Term Evolution
ME	Mobile Equipment
RAT	Radio Access Technology
SAR	Specific Absorption Rate
TA	Terminal Adapter
WCDMA	Wideband Code Division Multiple Access