

BC66

AT Commands Manual

NB-IoT Module Series

Rev. BC66_AT_Commands_Manual_V1.0

Date: 2018-08-28

Status: Released



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

Quectel Wireless Solutions Co., Ltd.

7th Floor, Hongye Building, No.1801 Hongmei Road, Xuhui District, Shanghai 200233, China

Tel: +86 21 5108 6236

Email: info@quectel.com

Or our local office. For more information, please visit:

<http://www.quectel.com/support/sales.htm>

For technical support, or to report documentation errors, please visit:

<http://www.quectel.com/support/technical.htm>

Or email to: support@quectel.com

GENERAL NOTES

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

COPYRIGHT

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL WIRELESS SOLUTIONS CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2018. All rights reserved.

About the Document

History

Revision	Date	Author	Description
1.0	2018-08-28	Randy LI/ Lebron LIU/ Souly YAN	Initial

Contents

About the Document	2
Contents	4
Table Index	6
1 Introduction	7
1.1. Definitions	7
1.2. AT Command Syntax.....	7
1.3. 3GPP Compliance	8
2 Implementation Status	9
3 3GPP Commands (27.007)	12
3.1. ATI Display Product Identification.....	12
3.2. ATE Set Command Echo Mode.....	13
3.3. AT&W Store Current Parameters to User Defined Profile.....	13
3.4. AT+IPR Set TE-TA Fixed Local Rate	14
3.5. AT+CGMI Request Manufacturer Identification.....	16
3.6. AT+CGMM Request Model Identification	16
3.7. AT+CGMR Request Manufacturer Revision.....	17
3.8. AT+CSQ Signal Quality Report.....	18
3.9. AT+CESQ Extended Signal Quality.....	19
3.10. AT+CGSN Request Product Serial Number	21
3.11. AT+CPIN Enter PIN	23
3.12. AT+CEREG EPS Network Registration Status.....	24
3.13. AT+CSCON Signalling Connection Status	28
3.14. AT+COPS Operator Selection	29
3.15. AT+CGATT PS Attach or Detach	32
3.16. AT+CGDCONT Define a PDP Context.....	33
3.17. AT+CGACT PDP Context Activation/Deactivation.....	37
3.18. AT+CGPADDR Show PDP Addresses	39
3.19. AT+CIMI Request International Mobile Subscriber Identity.....	42
3.20. AT+CFUN Set UE Functionality.....	42
3.21. AT+CMEE Report Mobile Termination Error.....	44
3.22. AT+CCLK Return Current Date and Time	45
3.23. AT+CBC Query Power Supply Voltage.....	46
3.24. AT+CPSMS Power Saving Mode Setting.....	47
3.25. AT+CEDRXS eDRX Setting.....	49
3.26. AT+CEDRXRDP eDRX Read Dynamic Parameters	52
3.27. AT+CTZR Time Zone Reporting	54
3.28. AT+CIPCA Initial PDP Context Activation.....	55
3.29. AT+CCIOTOPT CloT Optimization Configuration.....	57
3.30. AT+CGAPNRC APN Rate Control.....	59
3.31. AT+CEER Extended Error Report	60

4	General Commands	62
4.1.	AT+QGACTION Activate/Deactivate a PDN Context	62
4.2.	AT+QBAND Get and Set Mobile Operation Band	64
4.3.	AT+QRST Automatically Reset.....	66
4.4.	AT+QSPCHSC Set Scrambling Algorithm	66
4.5.	AT+QLOCKF Lock NB-IoT Frequency.....	67
4.6.	AT+QCSEARFCN Clear NB-IoT Stored EARFCN List.....	68
4.7.	AT+QCGDEFCONT Set Default PSD Connection Settings	69
4.8.	AT+QNBIOTRAI NB-IoT Release Assistance Indication	70
4.9.	AT+QNBIOTEVENT Enable/Disable NB-IoT Related Event Report	71
4.10.	AT+QATWAKEUP Enable/Disable Deep Sleep Wakeup Indication.....	72
4.11.	AT+QENG Engineering Mode.....	73
4.12.	AT+QCCID USIM Card Identification.....	76
4.13.	AT+QPOWD Power off the Module	77
4.14.	AT+QSCLK Configure Sleep Mode	78
5	Examples	79
5.1.	Network Attachment.....	79
5.1.1.	Manual Query of Network Attachment State	79
5.1.2.	Automatic Network Attachment State Report via URC.....	81
5.1.3.	Automatic Network Attachment with Specified PLMN/EARFCN/PCI/Band	83
6	Summary of <err> Codes	89
7	Appendix A Reference	92

Table Index

TABLE 1: TYPES OF AT COMMANDS AND RESPONSES	8
TABLE 2: TYPES OF AT COMMANDS AND IMPLEMENTATION STATUS	9
TABLE 3: GENERAL <ERR> CODES (27.007)	89
TABLE 4: SPECIFIC <ERR> CODES	90
TABLE 5: TERMS AND ABBREVIATIONS	92

1 Introduction

This document gives details of the AT Command Set supported by Quectel NB-IoT BC66 module.

By default, the module is in auto-baud mode. When powering on the module, the MCU has to send **AT** command consecutively to synchronize baud rate with the module until **OK** is returned. After successful synchronization, the MCU can send **AT+IPR=<rate>** command to configure the baud rate for communication afterwards. If the baud rate is not specified, re-synchronization should be executed in the next restart.

1.1. Definitions

- <CR>: Carriage return character
- <LF>: Line feed character
- <.>: Parameter name. Angle brackets do not appear on command line
- [..]: Optional parameter. Square brackets do not appear on the command line

1.2. AT Command Syntax

The “**AT**” or “**at**” prefix must be set at the beginning of each command line. Entering <CR> will terminate a command line. Commands are usually followed by a response that includes “<CR><LF><response><CR><LF>”. Throughout this document, only the responses are presented, “<CR><LF>” are omitted intentionally.

AT commands implemented by BC66 can be split into three categories syntactically: “**basic**”, “**S parameter**”, and “**extended**”. They are listed as follows:

- **Basic syntax**

These AT commands have the format of “**AT<x><n>**”, or “**AT&<x><n>**”, where “<x>” is the command, and “<n>” is/are the argument(s) for that command. An example of this is “**ATE<n>**”, which tells the DCE whether received characters should be echoed back to the DTE according to the value of “<n>”. “<n>” is optional and a default will be used if it is missing.

- **S parameter syntax**

These AT commands have the format of “**ATS<n>=<m>**”, where “<n>” is the index of the **S** register to set, and “<m>” is the value to assign to it. “<m>” is optional; if it is missing, then a default value is assigned.

- **Extended syntax**

These commands can be operated in several modes, as following table:

Table 1: Types of AT Commands and Responses

Test Command	AT+<x>=?	This command returns the list of parameters and value ranges set by the corresponding Write Command or internal processes.
Read Command	AT+<x>?	This command returns the currently set value of the parameter or parameters.
Write Command	AT+<x>=<...>	This command sets the user-definable parameter values.
Execution Command	AT+<x>	This command reads non-variable parameters affected by internal processes in the module.

NOTE

Each time a single AT command is supported. Only when execution of the previous AT command is finished, the next AT command will be executed.

1.3. 3GPP Compliance

3GPP commands are complied with the *3GPP TS 27.007*, *3GPP TS 27.005* and *ITU V.250* specifications.

2 Implementation Status

Table 2: Types of AT Commands and Implementation Status

AT Command	Description	Implementation Status
3GPP Commands (27.007)		
ATI	Display Product Identification Information	NBR01A01 or later
ATE	Set Command Echo Mode	NBR01A01 or later
AT&W	Store Current Parameters to User Defined Profile	NBR01A01 or later
AT+IPR	Set TE-TA Fixed Local Rate	NBR01A01 or later
AT+CGMI	Request Manufacturer Identification	NBR01A01 or later
AT+CGMM	Request Model Identification	NBR01A01 or later
AT+CGMR	Request Manufacturer Revision	NBR01A01 or later
AT+CSQ	Signal Quality Report	NBR01A01 or later
AT+CESQ	Extended Signal Quality	NBR01A01 or later
AT+CGSN	Request Product Serial Number	NBR01A01 or later
AT+CPIN	Enter PIN	NBR01A01 or later
AT+CEREG	EPS Network Registration Status	NBR01A01 or later
AT+CSCON	Signalling Connection Status	NBR01A01 or later
AT+COPS	Operator Selection	NBR01A01 or later
AT+CGATT	PS Attach or Detach	NBR01A01 or later
AT+CGDCONT	Define a PDP Context	NBR01A01 or later
AT+CGACT	PDP Context Activation or Deactivation	NBR01A01 or later

AT+CGPADDR	Show PDP Addresses	NBR01A01 or later
AT+CIMI	Request International Mobile Subscriber Identity	NBR01A01 or later
AT+CFUN	Set UE Functionality	NBR01A01 or later
AT+CMEE	Report Mobile Termination Error	NBR01A01 or later
AT+CCLK	Return Current Date and Time	NBR01A01 or later
AT+CBC	Query Power Supply Voltage	NBR01A02 or later
AT+CPSMS	Power Saving Mode Setting	NBR01A01 or later
AT+CEDRXS	eDRX Setting	NBR01A01 or later
AT+CEDRXRDP	eDRX Read Dynamic Parameters	NBR01A01 or later
AT+CTZR	Time Zone Reporting	NBR01A01 or later
AT+CIPCA	Initial PDP Context Activation	NBR01A01 or later
AT+CCIOPT	CloT Optimization Configuration	NBR01A01 or later
AT+CGAPNRC	APN Rate Control	NBR01A01 or later
AT+CEER	Extended Error Report	NBR01A01 or later
General Commands		
AT+QGACT	Activate/Deactivate a PDN Context	NBR01A01 or later
AT+QBAND	Get and Set Mobile Operation Band	NBR01A01 or later
AT+QRST	Automatically Rest	NBR01A01 or later
AT+QSPCHSC	Set Scrambling Algorithm	NBR01A01 or later
AT+QLOCKF	Lock NB-IoT Frequency	NBR01A01 or later
AT+QCSEARFCN	Clear NB-IoT Stored EARFCN List	NBR01A01 or later
AT+QCGDEFCONT	Set Default PSD Connection Settings	NBR01A01 or later
AT+QNBIOTRAI	NB-IoT Release Assistance Indication	NBR01A01 or later
AT+QNBIOTEVENT	Enable/Disable NB-IoT Related Event Report	NBR01A01 or later
AT+QATWAKEUP	Enable/Disable Deep Sleep Wakeup Indication	NBR01A01 or later

AT+QENG	Engineering Mode	NBR01A01 or later
AT+QCCID	USIM Card Identification	NBR01A01 or later
AT+QPOWD	Power off the Module	NBR01A02 or later
AT+QSCLK	Configure Sleep Mode	NBR01A02 or later

3 3GPP Commands (27.007)

3.1. ATI Display Product Identification Information

The execution command returns product identification information.

ATI Display Product Identification Information

Execution Command	Response
ATI	Quectel_Ltd <Object Id> Revision: <revision>
	OK
Maximum Response Time	300ms

Parameter

<Object Id>	Identifier of device type
<revision>	Revision of software release

Example

```
ATI
Quectel_Ltd
Quectel_BC66
Revision: BC66NBR01A01

OK
```

3.2. ATE Set Command Echo Mode

The execution command determines whether or not the UE echoes characters received from external MCU during command state.

ATE Set Command Echo Mode

Execution Command	Response
ATE<value>	OK
Maximum Response Time	300ms

Parameter

<value>	0	Echo mode OFF
	1	Echo mode ON

Example

```

ATE0
OK
ATI
Quectel_Ltd
Quectel_BC66
Revision: BC66NBR01A01

OK
ATE1
OK
ATI
Quectel_Ltd
Quectel_BC66
Revision: BC66NBR01A01

OK
    
```

3.3. AT&W Store Current Parameters to User Defined Profile

The command stores the current parameter settings to a user defined profile in non-volatile memory.

AT&W Store Current Parameters to User Defined Profile

Execution Command AT&W[<n>]	Response OK
Maximum Response Time	300ms

Parameter

<n> 0 Profile number to store current parameters

3.4. AT+IPR Set TE-TA Fixed Local Rate

Please refer to **Chapter 6** for possible <err> values.

AT+IPR Set TE-TA Fixed Local Rate

Test Command AT+IPR=?	Response +IPR: (list of preferred auto baud <rate>s),(list of supported fixed-only <rate>s) OK
Read Command AT+IPR?	Response +IPR: <rate> OK
Write Command AT+IPR=<rate>	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<rate>	Baud rate per second
	<u>0</u> (Auto baud)
	110
	300
	1200
	2400
	4800
	9600
	19200
	38400
	57600
	115200
	230400
	460800
	921600

NOTES

1. The setting will apply to all channels routed through one connection level for UART.
2. The command is not applicable for USB interface.

Example

```
AT+IPR=115200 //Set the fixed baud rate to 115200bps.
OK
AT&W //Store the current setting, that is, set the UART port communication
rate into 115200bps after resetting module.
OK
AT+IPR?
+IPR: 115200

OK
AT+IPR=?
+IPR: (4800,9600,115200),(0,110,300,1200,2400,4800,9600,19200,38400,57600,115200,230400,4608
00,921600)

OK
```

3.5. AT+CGMI Request Manufacturer Identification

The execution command returns manufacturer information.

AT+CGMI Request Manufacturer Identification	
Test Command AT+CGMI=?	Response OK
Execution Command AT+CGMI	Response Quectel_Ltd <Object Id> Revision: MTK_2625 OK
Maximum Response Time	300ms

Parameter

<Object Id> Identifier of device type

Example

```
AT+CGMI
Quectel_Ltd
Quectel_BC66
Revision: MTK_2625

OK
```

3.6. AT+CGMM Request Model Identification

The execution command returns the model information of the product.

AT+CGMM Request Model Identification	
Test Command AT+CGMM=?	Response OK
Execution Command AT+CGMM	Response <Object Id>

	OK
Maximum Response Time	300ms

Parameter

<Object Id> Identifier of device type

Example

```
AT+CGMM
Quectel_BC66
OK
```

3.7. AT+CGMR Request Manufacturer Revision

The execution command returns the manufacturer revision. The text is human-readable and is not intended for microcontroller parsing. By default it will return the firmware revision.

The execution command returns one line of information text <revision>.

AT+CGMR Request Manufacturer Revision	
Test Command AT+CGMR=?	Response OK
Execution Command AT+CGMR	Response Revision: <revision> OK
Maximum Response Time	300ms

Parameter

<revision> Revision of software release

Example

```
AT+CGMR
```

Revision: BC66NBR01A01

OK

3.8. AT+CSQ Signal Quality Report

The execution command returns the received signal strength level <rss> and the channel bit error rate <ber> from the MT.

The test command returns supported values as a compound value.

Please refer to **Chapter 6** for possible <err> values.

AT+CSQ Signal Quality Report

Test Command AT+CSQ=?	Response +CSQ: (list of supported <rss>s),(list of supported <ber>s) OK
Execution Command AT+CSQ	Response +CSQ: <rss>,<ber> OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<rss>	Integer type. Received signal strength level
0	-113dBm or less
1	-111dBm
2...30	-109...-53dBm
31	-51dBm or greater
99	Not known or not detectable
<ber>	Integer type. Channel bit error rate (in percent)
0...7	As RXQUAL values RXQUAL_0...RXQUAL_7 as defined in 3GPP TS 45.008
99	Not known or not detectable

Example

```
AT+CSQ
+CSQ: 22,0

OK
```

3.9. AT+CESQ Extended Signal Quality

The execution command returns received signal quality parameters.

The terminal will provide a current signal strength indicator of 0 to 99 where larger is generally better. This information is based on a single measurement so can be expected to change greatly over short periods of time and may never use all (or even the majority) of the entire possible range or codes.

The test command returns supported values as a compound value.

Please refer to **Chapter 6** for possible <err> values.

AT+CESQ Extended Signal Quality

Test Command AT+CESQ=?	Response +CESQ: (list of supported <rxlev>s),(list of supported <ber>s),(list of supported <rscp>s),(list of supported <ecno>s),(list of supported <rsrq>s),(list of supported <rsrp>s) OK
Execution Command AT+CESQ	Response +CESQ: <rxlev>,<ber>,<rscp>,<ecno>,<rsrq>,<rsrp> OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<rxlev>	Integer type. Received signal strength level
0	<rssi> < -110dBm
1	-110dBm ≤ <rssi> < -109dBm
2	-109dBm ≤ <rssi> < -108dBm
...	
61	-50dBm ≤ <rssi> < -49dBm
62	-49dBm ≤ <rssi> < -48dBm
63	-48dBm ≤ <rssi>
99	Not known or not detectable
<ber>	Integer type. Channel bit error rate (in percent)
0...7	As RXQUAL values RXQUAL_0...RXQUAL_7 as defined in 45.008.
99	Not known or not detectable
<rsrp>	Integer type, received signal code power (see 3GPP 25.133 and 3GPP 25.123)
0	-120 dBm or less
1	-120 dBm ≤ <rsrp> < -119 dBm
2	-119 dBm ≤ <rsrp> < -118 dBm
...	
94	-27 dBm ≤ <rsrp> < -26 dBm
95	-26 dBm ≤ <rsrp> < -25 dBm
96	-25 dBm ≤ <rsrp>
255	Not known or not detectable
<ecno>	Integer type, Ec/No (see 3GPP 25.133)
0	-24 dBm or less
1	-24dBm ≤ <ecno> < -23.5 dBm
2	-23.5dBm ≤ <ecno> < -23 dBm
...	
47	-1dBm ≤ <ecno> < -0.5 dBm
48	-0.5dBm ≤ <ecno> < 0 dBm
49	0 dBm ≤ <ecno>
255	Not known or not detectable
<rsrq>	Integer type. Reference signal received quality (see 3GPP 36.133)
0	-19.5dB or less
1	-19.5dB ≤ <rsrq> < -19dB
2	-19dB ≤ <rsrq> < -18.5dB
...	
32	-4dB ≤ <rsrq> < -3.5dB
33	-3.5dB ≤ <rsrq> < -3dB
34	-3dB ≤ <rsrq>
255	Not known or not detectable
<rsrp>	Integer type. Reference signal received power (see 3GPP 36.133)
0	-140 dBm or less
1	-140dBm ≤ <rsrp> < -139 dBm

2	-139dBm ≤ <rsrp> < -138 dBm
...	
95	-46dBm ≤ <rsrp> < -45 dBm
96	-45dBm ≤ <rsrp> < -44 dBm
97	-44dBm ≤ <rsrp>
255	Not known or not detectable

Example

AT+CESQ

+CESQ: 15,99,255,255,8,30

OK

NOTE

<rscp> and <ecno> are not applicable for BC66 so they should be set to the “not known or not detectable” value: 255.

3.10. AT+CGSN Request Product Serial Number

The execution command returns the IMEI (International Mobile station Equipment Identity) number and related information. For a TA which does not support <snt>, only “OK” is returned.

Please refer to **Chapter 6** for possible <err> values.

AT+CGSN Request Product Serial Number

Test Command

AT+CGSN=?

Response

When TE supports <snt> and the command is executed successfully:

+CGSN: (list of supported <snt>s)

OK

Write Command

AT+CGSN=<snt>

Response

When <snt>=0

<sn>

OK

When <snt>=1

+CGSN: <imei>

	<p>OK</p> <p>When <snt>=2 +CGSN: <imeisv></p> <p>OK</p> <p>When <snt>=3 +CGSN: <svn></p> <p>OK</p> <p>If there is any error, response: ERROR or +CME ERROR: <err></p>
<p>Execution Command AT+CGSN</p>	<p>Response <sn></p> <p>OK</p> <p>If there is any error, response: ERROR or +CME ERROR: <err></p>
<p>Maximum Response Time</p>	<p>300ms</p>

Parameter

<snt>	Integer type indicating the serial number type that has been requested
0	Returns the 128-bit UUID
1	Returns the IMEI number
2	Returns the IMEISV (International Mobile station Equipment Identity and Software Version) number
3	Returns the SVN (Software Version Number)
<sn>	The 128-bit UUID of the UE. The total number of characters, including line terminators. The information text shall not exceed 2048 characters, and shall not contain the sequence 0 <CR> or OK<CR>.
<imei>	String type in decimal format indicating the IMEI number
<imeisv>	String type in decimal format indicating the IMEISV
<svn>	String type in decimal format indicating the current SVN which is a part of IMEISV

Example

```
AT+CGSN=1 //Request the IMEI number
+CGSN: 490154203237511

OK
```

3.11. AT+CPIN Enter PIN

Please refer to **Chapter 6** for possible <err> values.

AT+CPIN Enter PIN

Test Command	Response
AT+CPIN=?	OK
Read Command AT+CPIN?	Response TA returns an alphanumeric string indicating whether or not some password is required. +CPIN: <code> OK
Write Command AT+CPIN=<pin>[,<new pin>][,<new pin>]	Response TA stores a password, such as USIM PIN, USIM PUK, PH-SIM PIN, etc., which is necessary before it can be operated. If the PIN is to be entered twice, the TA shall automatically repeat the PIN. If no PIN request is pending, no action is taken and an error message, +CME ERROR , is returned to TE. If the PIN required is USIM PUK or USIM PUK2, the second pin is required. This second pin, <new pin> , is used to replace the old pin in the USIM. When a new password is set, a third optional parameter may also be specified. This extra parameter is compared to the new password to check they are equivalent as an additional security feature. OK If there is any error, response: ERROR or +CME ERROR: <err>

Maximum Response Time	5s
-----------------------	----

Parameter

<code>	READY	No further entry needed
	SIM PIN	MT is waiting for USIM PIN
	SIM PUK	MT is waiting for USIM PUK
	PH_SIM PIN	MT is waiting for phone-to-USIM card password (antitheft)
	PH_NET PIN	Network personalization password is required.
	PH_NETSUB PIN	Network subset is required.
	PH_SP PIN	Service provider personalization password is required.
	PH_CORP PIN	Corporate personalization password is required.
	SIM PIN2	MT is waiting for USIM PIN 2 to be given. Possible only if the preceding command was acknowledged with "+CME ERROR:17"
	SIM PUK2	MT is waiting for USIM PUK 2 to be given. Possible only if the preceding command was acknowledged with error "+CME ERROR: 18"
<pin>	String type. Password	
<new pin>	String type. If the PIN required is USIM PUK or USIM PUK2, it is the new password.	

Example

```
AT+CPIN?
+CPIN: READY

OK
```

3.12. AT+CEREG EPS Network Registration Status

The write command controls the presentation of an unsolicited result code (URC) "+CEREG: <stat>" when <n>=1 and there is a change in the MT's EPS network registration status in E-UTRAN, or unsolicited result code "+CEREG: <stat>,[<tac>],[<ci>],[<AcT>]" when <n>=2 and there is a change of the network cell in E-UTRAN. The parameters <AcT>, <tac> and <ci> are provided only if available. The value <n>=3 further extends the unsolicited result code with [<cause_type>,<reject_cause>], when available, when the value of <stat> changes.

If the UE requests PSM for reducing its power consumption, the write command controls the presentation of an unsolicited result code: "+CEREG: <stat>,[<tac>],[<ci>],[<AcT>],[<cause_type>],[<reject_cause>],[<Active-Time>],[<Periodic-TAU>]]]".

When $\langle n \rangle = 4$, the unsolicited result code will provide the UE with additional information for the active time value and the extended periodic TAU value if there is a change of the network cell in E-UTRAN. The value $\langle n \rangle = 5$ further enhances the unsolicited result code with $\langle \text{cause_type} \rangle$ and $\langle \text{reject_cause} \rangle$ when the value of $\langle \text{stat} \rangle$ changes. The parameters $\langle \text{AcT} \rangle$, $\langle \text{tac} \rangle$, $\langle \text{ci} \rangle$, $\langle \text{cause_type} \rangle$, $\langle \text{reject_cause} \rangle$, $\langle \text{Active-Time} \rangle$ and $\langle \text{Periodic-TAU} \rangle$ are provided only if available.

The read command returns the status of result code presentation and an integer $\langle \text{stat} \rangle$ which shows whether the network has currently indicated the registration of the MT. Location information elements $\langle \text{tac} \rangle$, $\langle \text{ci} \rangle$ and $\langle \text{AcT} \rangle$, if available, are returned only when $\langle n \rangle = 2$ and MT is registered on the network. The parameters $[\langle \text{cause_type} \rangle, \langle \text{reject_cause} \rangle]$, if available, are returned when $\langle n \rangle = 3$.

The test command returns supported parameter values.

Please refer to **Chapter 6** for possible $\langle \text{err} \rangle$ values.

AT+CEREG EPS Network Registration Status	
Test Command AT+CEREG=?	Response +CEREG: (list of supported $\langle n \rangle$ s) OK
Read Command AT+CEREG?	Response When $\langle n \rangle = 0, 1, 2$ or 3 and the command is executed successfully: +CEREG: $\langle n \rangle, \langle \text{stat} \rangle, [\langle \text{tac} \rangle], [\langle \text{ci} \rangle], [\langle \text{AcT} \rangle], [\langle \text{cause_type} \rangle, \langle \text{reject_cause} \rangle]$ When $\langle n \rangle = 4$ or 5 and the command is executed successfully: +CEREG: $\langle n \rangle, \langle \text{stat} \rangle, [\langle \text{lac} \rangle], [\langle \text{ci} \rangle], [\langle \text{AcT} \rangle], [\langle \text{cause_type} \rangle], [\langle \text{reject_cause} \rangle], [\langle \text{Active-Time} \rangle], [\langle \text{Periodic-TAU} \rangle]$ OK If there is any error, response: ERROR or +CME ERROR: $\langle \text{err} \rangle$
Write Command AT+CEREG=$\langle n \rangle$	Response OK If there is any error, response: ERROR or +CME ERROR: $\langle \text{err} \rangle$

Maximum Response Time	300ms
-----------------------	-------

Parameter

<n>	Integer type <ul style="list-style-type: none"> 0 Disable network registration unsolicited result code 1 Enable network registration unsolicited result code: "+CEREG: <stat>" 2 Enable network registration and location information unsolicited result code: "+CEREG: <stat>[,<tac>],[<ci>],[<AcT>]" 3 Enable network registration, location information and EMM cause value information unsolicited result code: "+CEREG: <stat>[,<tac>],[<ci>],[<AcT>][,<cause_type>,<reject_cause>]" 4 For a UE that requests PSM, enable network registration and location information unsolicited result code: "+CEREG: <stat>[,<tac>],[<ci>],[<AcT>][,],[<Active-Time>],[<Periodic-TAU>]" 5 For a UE that requests PSM, enable network registration, location information and EMM cause value information unsolicited result code: "+CEREG: <stat>[,<lac>],[<ci>],[<AcT>][,<cause_type>],[<reject_cause>][,<Active-Time>],[<Periodic-RAU>]"
<stat>	Integer type. The EPS registration status. <ul style="list-style-type: none"> 0 Not registered, MT is not currently searching an operator to register to 1 Registered, home network 2 Not registered, but MT is currently trying to attach or searching an operator to register to 3 Registration denied 4 Unknown (e.g. out of E-UTRAN coverage) 5 Registered, roaming
<tac>	String type. Two bytes tracking area code in hexadecimal format (e.g. "00C3" equals 195 in decimal).
<ci>	String type. Four bytes E-UTRAN cell ID in hexadecimal format.
<AcT>	Integer type. Access technology of the registered network. <ul style="list-style-type: none"> 7 E-UTRAN 9 E-UTRAN (NB-S1 mode)
<cause_type>	Integer type. The type of <reject_cause>. <ul style="list-style-type: none"> 0 Indicates that <reject_cause> contains an EMM cause value (see <i>3GPP TS 24.008[8] Annex G</i>). 1 Indicates that <reject_cause> contains a manufacturer-specific cause value
<reject_cause>	Integer type. Contains the cause of the failed registration. The value is of type as defined by <cause_type>.
<Active-Time>	String type. One byte in an 8-bit format. Indicates the active time value (T3324) allocated to the UE in E-UTRAN. The active time value is coded as one byte (octet 3) of the GPRS Timer 2 information element coded as bit format (e.g. "00100100" equals 4 minutes). For the coding and the value range, please refer to the <i>GPRS Timer 2 IE</i>

in 3GPP TS 24.008 Table 10.5.163/3Gpp TS 24.008, 3GPP TS 23.682 and 3GPP TS 23.401.

Bits 5 to 1 represent the binary coded timer value.

Bits 6 to 8 defines the timer value unit for the GPRS timer as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 2 seconds

0 0 1 value is incremented in multiples of 1 minute

0 1 0 value is incremented in multiples of decihours

1 1 1 value indicates that the timer is deactivated.

<Periodic-TAU> String type. One byte in an 8-bit format. Indicates the extended periodic TAU value (T3412) allocated to the UE in E-UTRAN. The extended periodic TAU value is coded as one byte (octet 3) of the GPRS Timer 3 information element coded as bit format (e.g. "01000111" equals 70 hours). For the coding and the value range, please refer to the *GPRS Timers 3 IE in 3GPP TS 24.008 Table 10.5.163a/3GPP TS 24.008, 3GPP TS 23.682 and 3GPP TS 23.401*.

Bits 5 to 1 represent the binary coded timer value

Bits 6 to 8 define the timer value unit as follows:

Bits

8 7 6

0 0 0 value is incremented in multiples of 10 minutes

0 0 1 value is incremented in multiples of 1 hour

0 1 0 value is incremented in multiples of 10 hours

0 1 1 value is incremented in multiples of 2 seconds

1 0 0 value is incremented in multiples of 30 seconds

1 0 1 value is incremented in multiples of 1 minute

1 1 0 value is incremented in multiples of 320 hours

1 1 1 value indicates that the timer is deactivated

Example

```
AT+CEREG=1           //Enable network registration URC.
OK
AT+CEREG?
+CEREG: 1,1

OK
AT+CEREG=?
+CEREG: (0-5)

OK
```

3.13. AT+CSCON Signalling Connection Status

The command gives details of the TA's perceived radio connection status (i.e. to the base station). It returns an indication of the current state. Please note that this state is only updated when radio events, such as sending and receiving, take place. This means that the current state may be out of date. The terminal may think it is "Connected" yet cannot currently use a base station due to a change in the link quality.

The write command controls the presentation of an unsolicited result code. If $\langle n \rangle = 1$, "+CSCON: $\langle mode \rangle$ " is sent from the MT when the connection mode of the MT is changed.

When the MT is in E-UTRAN, the mode of the MT refers to idle when no PS signaling connection and to connected mode when a PS signalling connection between MT and network is setup.

The $\langle state \rangle$ value indicates the state of the MT when the MT is in E-UTRAN.

The read command returns the status of result code presentation and an integer $\langle mode \rangle$ which shows whether the MT is currently in idle mode or connected mode.

The test command returns supported values as a compound value.

Please refer to **Chapter 6** for possible $\langle err \rangle$ values.

AT+CSCON Signalling Connection Status	
Test Command AT+CSCON=?	Response +CSCON: (list of supported $\langle n \rangle$ s) OK
Read Command AT+CSCON?	Response +CSCON: $\langle n \rangle, \langle mode \rangle [, \langle state \rangle]$ OK If there is any error, response: ERROR Or +CME ERROR: $\langle err \rangle$
Write command AT+CSCON=$\langle n \rangle$	Response OK If there is any error, response: ERROR or +CME ERROR: $\langle err \rangle$

Maximum Response Time	300ms
-----------------------	-------

Parameter

<n>	Integer type. Enable/disable unsolicited result code.
0	Disable unsolicited result code
1	Enable unsolicited result code: "+CSCON:<mode>"
<mode>	Integer type. The signalling connection status.
0	Idle
1	Connected

Example

```

AT+CSCON=0
OK
AT+CSCON?
+CSCON: 0,1

OK
AT+CSCON=?
+CSCON: (0,1)

OK
AT+CSCON=1
OK
AT+CSCON?
+CSCON: 1,1

OK

```

3.14. AT+COPS Operator Selection

The write command forces an attempt to select and register the EPS network operator using the USIM card installed in the currently selected card slot. <mode> is used to select whether the selection is done automatically by the MT or is forced by this command to operator <oper> (it shall be given in format <format>) to a certain access technology, indicated in <AcT>. If the selected operator is not available, no other operator shall be selected (except <mode>=4). If the selected access technology is not available, then the same operator shall be selected in other access technology. The selected operator name format shall also apply to further read commands (AT+COPS?). <mode>=2 forces an attempt to deregister from the network. The selected mode affects all further network registration (e.g. after <mode>=2, MT shall be unregistered until <mode>=0 or 1 is selected). This command should be abortable when

registration/deregistration attempt is made.

The read command returns the current mode, the currently selected operator and the current access technology. If no operator is selected, <format>, <oper> and <AcT> are omitted.

The test command returns a set of five parameters, each representing an operator present in the network. A set consists of an integer indicating the availability of the operator <stat>, long and short alphanumeric format of the operator's name, numeric format representation of the operator and access technology. Any of the formats may be unavailable and should then be an empty field. The list of operators shall be in the order of: home network, networks referenced in USIM or active application in the UICC (USIM) in the following order: HPLMN selector, user controlled PLMN selector, operator controlled PLMN selector and PLMN selector (in the USIM), and other networks.

The <AcT> access technology selected parameters should only be used in terminals capable to register to more than one access technology. Selection of <AcT> does not limit the capability to cell reselections, even though an attempt is made to select an access technology, the phone may still re-select a cell in another access technology.

Please refer to **Chapter 6** for possible <err> values.

AT+COPS Operator Selection

<p>Test Command AT+COPS=?</p>	<p>Response +COPS: [list of supported (<stat>,numeric <oper>[,<AcT>])s][,,(list of supported <mode>s),(list of supported <format>s)]</p> <p>OK</p> <p>If there is any error, response: ERROR Or +CME ERROR: <err></p>
<p>Read Command AT+COPS?</p>	<p>Response +COPS: <mode>[,<format>,<oper>][,<AcT>]</p> <p>OK</p> <p>If there is any error, response: ERROR Or +CME ERROR: <err></p>
<p>Write Command AT+COPS=<mode>[,<format>,<oper>[,<AcT>]]</p>	<p>Response OK</p>

	If there is any error, response: ERROR Or +CME ERROR: <err>
Maximum Response Time	630s

Parameter

<mode>	Integer type <ul style="list-style-type: none"> 0 Automatic mode (<oper> field is ignored) 1 Manual operator selection (<oper> field shall be present) 2 Manual deregister from network 3 Set only <format> (for read command AT+COPS?), not shown in Read command response 4 Manual/automatic selected. If manual selection fails, automatic mode (<mode>=0) is entered
<format>	Integer type 2 Numeric <oper>
<oper>	String type. <format> indicates if the format is numeric; numeric format is the NB-IoT network location area identification number which consists of a three BCD digit ITU-T country code coded, plus a two or three BCD digit network code, which is administration specific. <oper> field could not be present when <mode>=0.
<stat>	Integer type <ul style="list-style-type: none"> 0 Unknown 1 Operator Available 2 Operator Current 3 Operator Forbidden
<AcT>	Integer type. Access technology selected <ul style="list-style-type: none"> 7 E-UTRAN 9 E-UTRAN (NB-S1 mode)

NOTE

The test command can only be executed in idle state, otherwise an error will be returned.

Example

```
AT+COPS=0
OK
AT+COPS?
+COPS: 0,2,"46000",9
```

OK

3.15. AT+CGATT PS Attach or Detach

The write command is used to attach the MT to, or detach the MT from, the packet domain service. After the command has completed, the MT remains in V.250 command state. If the MT is already in the requested state, the command is ignored and the “OK” response is returned. If the requested state cannot be achieved, an “ERROR” or “+CME ERROR” response is returned. Please refer to **Chapter 6** for possible <err> values.

Any active PDP contexts will be automatically deactivated when the attachment state changes to detached.

The read command returns the current packet domain service state.

The test command is used for requesting information on the supported packet domain service states.

AT+CGATT PS Attach or Detach

Test Command AT+CGATT=?	Response +CGATT: (list of supported <state>s) OK
Read Command AT+CGATT?	Response +CGATT: <state> OK
Write Command AT+CGATT=<state>	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	75s, determined by network.

Parameter

<state>	Integer type. Indicates the state of PDP context activation.
0	Detached
1	Attached

When <state>=1, AT+COPS=0 is automatically selected.

NOTES

1. If the initial PDP context is supported, the context with <cid>=1 is automatically defined at startup.
2. If AT+CGATT is in progress, further execution of this command before the finishing of attach or detach procedure will return an error.

Example

```
AT+CGATT?  
+CGATT: 0  
  
OK  
  
AT+CGATT=1  
OK  
  
AT+CGATT=?  
+CGATT: (0,1)  
  
OK
```

3.16. AT+CGDCONT Define a PDP Context

The write command specifies PDP context parameters for a PDP context identified by the (local) context identification parameter, <cid>. It also allows the TE to specify whether security protected transmission of ESM information is requested, because the PCO can include information that requires ciphering. There can be other reasons for the UE to use security protected transmission of ESM information, e.g. if the UE needs to transfer an APN. The number of PDP contexts that may be in a defined state at the same time is given by the range returned by the test command. Please refer to **Chapter 6** for possible <err> values.

For EPS the PDN connection and its associated EPS default bearer is identified herewith. For EPS the <PDP_addr> shall be omitted.

A special form of the write command, AT+CGDCONT=<cid> causes the values for context number <cid> to become undefined.

The read command returns the current settings for each defined context.

The test command returns values supported as a compound value. If the UE supports several PDP types,

<PDP_type>, the parameter value ranges for each <PDP_type> are returned on a separate line.

By default, the context with <cid>=1 (context number 1) is defined upon startup and does not need to be created with the AT+CGDCONT command. The initial PDP context has particular manufacturer specific default settings disassociated with any other default settings of AT+CGDCONT. When in E-UTRAN, the initial PDP context is automatically activated by the MT following a successful registration to the network depending on the setting of AT+CIPCA command. If all active contexts are deactivated, the initial PDP context can be (re)established.

AT+CGDCONT Define a PDP Context

Test Command
AT+CGDCONT=?

Response

+CGDCONT: (list of supported <cid>s),(list of supported <PDP_type>s),,(list of supported <d_comp>s),(list of supported <h_comp>s),(list of supported <IPv4AddrAlloc>s),(list of supported <request_type>s),(list of supported <P-CSCF_discovery>s),(list of supported <IM_CN_Signalling_Flag_Ind>s),(list of supported <NSLPI>s),(list of supported <securePCO>s),(list of supported <IPv4_MTU_discovery>s),(list of supported <Local_Addr_Ind>s),(list of supported <Non-IPMTUDiscovery>s)

+CGDCONT: (list of supported of <cid>s),(list of supported <PDP_type>s),,(list of supported <d_comp>s),(list of supported <h_comp>s),(list of supported <IPv4AddrAlloc>s),(list of supported <request_type>s),(list of supported <P-CSCF_discovery>s),(list of supported <IM_CN_Signalling_Flag_Ind>s),(list of supported <NSLPI>s),(list of supported <securePCO>s),(list of supported <IPv4_MTU_discovery>s),(list of supported <Local_Addr_Ind>s),(list of supported <Non-IPMTUDiscovery>s)[...]

OK

Read Command
AT+CGDCONT?

Response

[+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<P-CSCF_discovery>[,<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery>[,<Local_Addr_Ind>[,<Non-IP_MTU_discovery>]]]]]]]]]

+CGDCONT: <cid>,<PDP_type>,<APN>,<PDP_addr>,<d_comp>,<h_comp>[,<IPv4AddrAlloc>[,<request_type>[,<P-CSCF_discovery>[,<IM_CN_Signalling_Flag_Ind>[,<NSLPI>[,<securePCO>[,<IPv4_MTU_discovery>[,<Local_Addr_Ind>[,<Non-IP_MTU_discovery>]]]]]]]]]

2	RFC 1144 (applicable for SNDCP only)
3	RFC 2507
4	RFC 3095[ROHC] (applicable for PDCP only)
<IPv4AddrAlloc>	Integer type. Controls how the MT/TA requests to get the IPv4 address information
0	IPv4 address allocation through NAS signalling
1	IPv4 address allocated through DHCP
<request_type>	Integer type. Indicates the type of PDP context activation request for the PDP context. Please refer to <i>3GPP TS 24.301 (subclause 6.5.1.2)</i> and <i>3GPP TS 24.008 (subclause 10.5.6.17)</i> . If the initial PDP context is supported it is not allowed to assign <cid>=0 for emergency bearer services. According to <i>3GPP TS 24.008 (subclause 4.2.4.2.2 and subclause 4.2.5.1.4)</i> and <i>3GPP TS 24.301 (subclause 5.2.2.3.3 and subclause 5.2.3.2.2)</i> , a separate PDP context must be established for emergency bearer services. If the PDP context for emergency bearer services is the only activated context, only emergency calls are allowed, refer to <i>3GPP TS 23.401 subclause 4.3.12.9</i> .
0	PDP context is for new PDP context establishment or for handover from a non-3GPP access network (how the MT decides whether the PDP context is for new PDP context establishment or for handover is implementation specific).
1	PDP context is for emergency bearer services
2	PDP context is for new PDP context establishment
3	PDP context is for handover from a non-3GPP access network
<P-CSCF_discovery>	Integer type. Influences how the MT/TA requests to get the P-CSCF address, refer to <i>3GPP TS 24.229 [89] annex B and annex L</i> .
0	Preference of P-CSCF address discovery not influenced by AT+CGDCONT
1	Preference of P-CSCF address discovery through NAS signalling
2	Preference of P-CSCF address discovery through DHCP
<IM_CN_Signalling_Flag_Ind>	Integer type. Indicates to the network whether the PDP context is for IM CN subsystem related signalling only or not.
0	UE indicates that the PDP context is not for IM CN subsystem-related signalling only
1	UE indicates that the PDP context is for IM CN subsystem-related signalling only
<NSLPI>	Integer type. Indicates the NAS signalling priority requested for this PDP context
0	Indicates that this PDP context is to be activated with the value for the low priority indicator configured in the MT.
1	Indicates that this PDP context is to be activated with the value for the low priority indicator set to "MS is not configured for NAS signalling low priority". The MT utilizes the provided NSLPI information as specified in <i>3GPP TS 24.301 [83]</i> and <i>3GPP TS 24.008</i> .
<securePCO>	Integer type. Specifies whether security protected transmission of

	PCO is requested or not (applicable for EPS only).
	<u>0</u> Security protected transmission of PCO is not requested
	1 Security protected transmission of PCO is requested
<IPv4_MTU_discovery>	Integer type. Influences how the MT/TA requests to get the IPv4 MTU size, refer to <i>3GPP TS 24.008 subclause 10.5.6.3</i> .
	<u>0</u> Preference of IPv4 MTU size discovery not influenced by AT+CGDCONT
	1 Preference of IPv4 MTU size discovery through NAS signaling
<Non-IP_MTU_discovery>	Integer type; influences how the MT/TA requests to get the Non-IP MTU size, refer to <i>3GPP TS 24.008 subclause 10.5.6.3</i> .
	<u>0</u> Preference of Non-IP MTU size discovery not influenced by AT+CGDCONT
	2 Preference of Non-IP MTU size discovery through NAS signaling

NOTES

1. Only 3 PDP contexts can be activated.
2. For EPS, <PDP_addr> field is omitted.
3. Parameters <IPv4AddrAlloc>, <request_type>, <P-CSCF_discovery>, <IM_CN_Signalling_Flag_Ind>, <NSLPI>, <securePCO> and <Local_Addr_Ind> are not supported in modem protocol.

Example

```

AT+CGDCONT=?
+CGDCONT: (1-15),"IP",,,(0-2),(0-4),(0),,,,,,(0,1),,(0,1)
+CGDCONT: (1-15),"IPV6",,,(0-2),(0-4),(0),,,,,,(0,1),,(0,1)
+CGDCONT: (1-15),"IPV4V6",,,(0-2),(0-4),(0),,,,,,(0,1),,(0,1)
+CGDCONT: (1-15),"Non-IP",,,(0-2),(0-4),(0),,,,,,(0,1),,(0,1)

OK
AT+CGDCONT=1,"IP","CMNET"
OK
AT+CGDCONT?
+CGDCONT: 1,"IP","CMNET",,"",0,0,0,,,,,0,0

OK

```

3.17. AT+CGACT PDP Context Activation/Deactivation

The write command is used to activate or deactivate the specified PDP context (s). After the command has completed, the MT remains in V.250 command state. If any PDP context is already in the requested

state, the state for that context remains unchanged. If the requested state for any specified context cannot be achieved, an “ERROR” or “+CME ERROR” response is returned. Extended error responses are enabled by the AT+CME command.

If the UE is not PS attached when the activation form of the command is executed, the UE first performs a PS attach and then attempts to activate the specified contexts. If the attach fails then the MT responds with an error or, if extended error responses are enabled, with the appropriate failure-to-attach error message.

Note that in the *3GPP TS 27.007* specification there is the following statement:

For EPS, if an attempt is made to disconnect the last PDN connection, then the UE responds with “ERROR” or, if extended error responses are enabled, a “+CME ERROR”.

For EPS, the activation request for an EPS bearer resource will be answered by the network by either an EPS dedicated bearer activation or EPS bearer modification request. The request must be accepted by the UE before the PDP context can be set into established state.

If no <cid>s are specified, the activation form of the command activates all defined non-emergency contexts, and the deactivation form of the command deactivates all active contexts.

The read command returns the current activation states for all the defined PDP contexts.

The test command is used for requesting information on the supported PDP context activation states.

Please refer to **Chapter 6** for possible <err> values.

AT+CGACT PDP Context Activation/Deactivation	
Test Command AT+CGACT=?	Response +CGACT: (list of supported <state>s) OK
Read Command AT+CGACT?	Response +CGACT: <cid>,<state> +CGACT: <cid>,<state> [...] OK
Write Command AT+CGACT=<state>[,<cid>[,<cid>[,...]]	Response If context is activated successfully: OK

	<p>If context is deactivated successfully: NO CARRIER</p> <p>If there is any error, response: ERROR or +CME ERROR: <err></p>
Maximum Response Time	150s, determined by network.

Parameter

<state>	Integer type. The state of PDP context activation. 0 Deactivated 1 Activated
<cid>	Integer type. A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command).

NOTE

If the initial PDP context is supported, the context with <cid>=1 is automatically defined at startup.

Example

```
AT+CGACT=0,1
OK
AT+CGACT?
+CGACT: 1,0

OK
AT+CGACT=?
+CGACT: (0,1)

OK
```

3.18. AT+CGPADDR Show PDP Addresses

The command returns the IP address of the device.

The execution command returns a list of PDP addresses for the specified context identifiers. If no <cid> is

specified, the addresses for all defined contexts are returned.

The test command returns a list of defined <cid>s. These are <cid>s that have been activated and may or may not have an IP address associated with them.

AT+CGPADDR Show PDP Addresses

Test Command AT+CGPADDR=?	Response +CGPADDR: (list of defined <cid>s) OK
Read Command AT+CGPADDR?	Response +CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [...] OK IPv4: The string is given as dot-separated numeric (0-255) parameter of the form: a1.a2.a3.a4 IPv6: The string is given as colon-separated hexadecimal parameter.
Write Command AT+CGPADDR[=<cid>[,<cid>[,...]]]	Response [+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [+CGPADDR: <cid>[,<PDP_addr_1>[,<PDP_addr_2>]] [...] OK IPv4: The string is given as dot-separated numeric (0-255) parameter of the form: a1.a2.a3.a4 IPv6: The string is given as colon-separated hexadecimal parameter.
Maximum Response Time	300ms

Parameter

<cid> Integer type. A numeric parameter which specifies a particular PDP context definition (see AT+CGDCONT command). If no <cid> is specified, the addresses for all defined contexts are returned.

<PDP_addr_1> and **<PDP_addr_2>**

String type. Identify the MT in the address space applicable to the PDP. The address may be static or dynamic.

For a static address, it will be the one set by the AT+CGDCONT command when the context was defined.

For a dynamic address it will be the one assigned during the last PDP context activation that used the context definition referred to by <cid>. <PDP_address> is omitted if none is available.

Both <PDP_addr_1> and <PDP_addr_2> are included when both IPv4 and IPv6 addresses are assigned, with <PDP_addr_1> containing the IPv4 address and <PDP_addr_2> containing the IPv6 address.

The string is given as dot-separated numeric (0-255) parameter of the form:

a1.a2.a3.a4 for IPv4 and a1.a2.a3.a4.a5.a6.a7.a8.a9.a10.a11.a12.a13.a14.a15.a16 for IPv6. When AT+CGPIAF is supported, its settings can influence the format of the IPv6 address in parameter <PDP_addr_1> or <PDP_addr_2> returned with the write form of AT+CGPADDR.

NOTES

1. In dual-stack terminals (<PDP_type>=IPv4v6), the IPv6 address will be provided in <PDP_addr_2>.
2. For terminals with a single IPv6 stack (<PDP_type>=IPv6) or due to backwards compatibility, the IPv6 address can be provided in parameter <PDP_addr_1>.

Example

```
AT+CGPADDR=1
+CGPADDR: 1,101.43.5.1
```

```
OK
```

```
AT+CGPADDR=?
+CGPADDR: (1)
```

```
OK
```

3.19. AT+CIMI Request International Mobile Subscriber Identity

The command returns International Mobile Subscriber Identity (string without double quotes).

The execution command causes the TA to return <IMSI>, which is intended to permit the TE to identify the individual USIM card or active application in the UICC (USIM) which is attached to MT.

Please refer to **Chapter 6** for possible <err> values.

AT+CIMI Request International Mobile Subscriber Identity

Test Command AT+CIMI=?	Response OK
Execution Command AT+CIMI	Response <IMSI> OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<IMSI> International Mobile Subscriber Identity (string without double quotes)

Example

```
AT+CIMI
460001357924680
OK
```

3.20. AT+CFUN Set UE Functionality

The write command selects the level of functionality in the MT. Level "full functionality" is where the highest level of power is drawn. "Minimum functionality" is where minimum power is drawn.

The read command returns the current setting of <fun>.

The test command returns values supported by the MT as compound values.

Please refer to **Chapter 6** for possible <err> values.

AT+CFUN Set UE Functionality

Test Command AT+CFUN=?	Response +CFUN: (list of supported <fun>s),(list of supported <rst>s) OK
Read Command AT+CFUN?	Response +CFUN: <fun> OK
Write Command AT+CFUN=<fun>[,<rst>]	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	15s, determined by network.

Parameter

<fun>	Integer type. UE functionality level
	0 Minimum functionality
	<u>1</u> Full functionality
	4 Disable the UE from both transmitting and receiving RF signals
<rst>	Integer type. UE resetting
	<u>0</u> Do not reset the UE before setting it to <fun> power level.
	1 Only set to <fun> power level after UE has been reset, and for all subsequent resets.
	2 Do not reset UE before setting it to <fun> power level and save <fun> value in NVRAM for all subsequent resets.

Example

```
AT+CFUN=?
+CFUN: (0,1,4,7),(0-2)

OK
```

```
AT+CFUN=1
OK
AT+CFUN?
+CFUN: 1
OK
```

3.21. AT+CMEE Report Mobile Termination Error

The write command disables or enables the use of final result code “+CME ERROR: <err>” as an indication of an error relating to the functionality of the MT. When enabled, MT related errors cause “+CME ERROR: <err>” final result code instead of the regular “ERROR” final result code. “ERROR” is returned normally when error is related to syntax, invalid parameters or TA functionality.

The read command returns the current setting of <n>.

The test command returns values supported as a compound value.

Please refer to **Chapter 6** for possible <err> values.

AT+CMEE Report Mobile Termination Error

Test Command AT+CMEE=?	Response +CMEE: (list of supported <n>s) OK
Read Command AT+CMEE?	Response +CMEE: <n> OK
Write Command AT+CMEE=<n>	Response TA disables or enables the use of result code “+CME ERROR: <err>” as an indication of an error relating to the functionality of the ME. OK
Maximum Response Time	300ms

Parameter

<n> Integer type

0	Disable result code
1	Enable result code and use numeric values
2	Enable result code and use verbose values

Example

```
AT+CMEE?
+CMEE: 0

OK
AT+CMEE=?
+CMEE: (0-2)

OK
```

3.22. AT+CCLK Return Current Date and Time

The clock will be set automatically once the UE has connected to the network.

The read command returns the current setting of the clock.

AT+CCLK Return Current Date and Time

Test Command AT+CCLK=?	Response OK
Read Command AT+CCLK?	Response +CCLK: <time> OK
Maximum Response Time	300ms

Parameter

<time>	String type. The format is "yy/MM/dd,hh:mm:ss±zz", where characters indicate year (two last digits), month, day, hour, minute, second and time zone (indicates the difference, expressed in quarters of an hour, between the local time and GMT; and range is -47 ~ +48). For instance, 6th of May 1994, 22:10:00 GMT+2 hours equals "94/05/06,22:10:00+08"
---------------------	---

NOTE

If MT does not support time zone information then the three last characters of <time> are not returned by AT+CCLK? command.

Example

```
AT+CCLK=?
OK
```

3.23. AT+CBC Query Power Supply Voltage

The commands is used to query the voltage value of power supply.

Please refer to **Chapter 6** for possible <err> values.

AT+CBC Query Power Supply Voltage

Test Command AT+CBC=?	Response +CBC: (list of supported <bcs>s),(list of supported <bcl>s),(voltage) OK
Execution Command AT+CBC	Response +CBC: <bcs>,<bcl>,<voltage> OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<bcs>	Battery charge status
	0 ME is not charging
	1 ME is charging
	2 Charging has been finished
<bcl>	Battery charge level

	0...100	Battery has 0-100 percent of capacity remaining vent
<voltage>		Battery voltage (mV)

NOTE

As BC66 does not support battery charge, <bcs> and <bcl> are invalid while the <voltage> still represents the correct voltage of power supply.

Example

```
AT+CBC
+CBC: 0,0,3368

OK
```

3.24. AT+CPSMS Power Saving Mode Setting

The write command controls the setting of the UE's power saving mode (PSM) parameters. It controls whether the UE wants to apply PSM or not, as well as the requested extended periodic TAU value in E-UTRAN and the requested Active Time value. See the unsolicited result codes provided by AT+CEREG for the Active Time value, and the extended periodic TAU value that are allocated to the UE by the network in E-UTRAN.

A special form of the command can be given as AT+CPSMS=2. In this form the use of PSM will be disabled and data for all parameters in AT+CPSMS command will be removed or, if available, set to the default values.

The read command returns the current parameter values.

The test command returns the supported <mode>s and the value ranges for the requested extended periodic TAU value in E-UTRAN and the requested Active Time value as compound values.

Please refer to **Chapter 6** for possible <err> values.

AT+CPSMS Power Saving Mode Setting

Test Command	Response
AT+CPSMS=?	+CPSMS: (list of supported <mode>s),,,(list of supported <Requested_Periodic-TAU>s),(list of supported <Requested_Active-Time>s)
	OK

Read Command AT+CPSMS?	Response +CPSMS: <mode>[,],[<Requested_Periodic-TAU>],[<Requested_Active-Time>] OK If there is any error, response: ERROR Or +CME ERROR: <err>
Write Command AT+CPSMS=<mode>[,],[<Requested_Periodic-TAU>],[<Requested_Active-Time>]	Response OK If there is any error, response: ERROR Or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode>	Integer type. Disable or enable the use of PSM in the UE 0 Disable the use of PSM <u>1</u> Enable the use of PSM 2 Disable the use of PSM and discard all parameters for PSM or, if available, reset to the default values.
<Requested_Periodic-TAU>	String type. One byte in an 8-bit format. Requested extended periodic TAU value (T3412) to be allocated to the UE in E-UTRAN. (e.g. "01000111" equals 70 hours). Bits 5 to 1 represent the binary coded timer value Bits 6 to 8 define the timer value unit as follows: Bits 8 7 6 0 0 0 value is incremented in multiples of 10 minutes 0 0 1 value is incremented in multiples of 1 hour 0 1 0 value is incremented in multiples of 10 hours 0 1 1 value is incremented in multiples of 2 seconds 1 0 0 value is incremented in multiples of 30 seconds 1 0 1 value is incremented in multiples of 1 minute 1 1 0 value is incremented in multiples of 320 hours 1 1 1 value indicates that the timer is deactivated
<Requested_Active-Time>	String type. One byte in an 8-bit format. Requested Active Time value (T3324) to be allocated to the UE.

(e.g. "00100100" equals 4 minutes).
 Bits 5 to 1 represent the binary coded timer value.
 Bits 6 to 8 defines the timer value unit for the GPRS timer as follows:

Bits	
8 7 6	
0 0 0	value is incremented in multiples of 2 seconds
0 0 1	value is incremented in multiples of 1 minute
0 1 0	value is incremented in multiples of decihours
1 1 1	value indicates that the timer is deactivated

NOTES

1. This timer value unit is only applicable to the T3412 extended value IE. If it is received in an integrity protected message, value shall be interpreted as multiples of 320 hours. Otherwise value shall be interpreted as multiples of 1 hour.
2. AT+CPSMS? read command could only get mode value 0 and 1.

Example

```
AT+CPSMS=1,,,"01000011","01000011"
OK
AT+CPSMS?
+CPSMS: 1,,,"01000011","01000011"

OK
AT+CPSMS=?
+CPSMS: (0-2),,("00000000"- "11111111"), ("00000000"- "11111111")

OK
```

3.25. AT+CEDRXS eDRX Setting

The write command controls the setting of the UE's eDRX parameters. The command controls whether the UE wants to apply eDRX or not, as well as the requested eDRX value for each specified type of access technology.

The write command also controls the presentation of an unsolicited result code "+CEDRXP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]" when <n>=2 and there is a change in the eDRX parameters provided by the network.

A special form of the command can be given as AT+CEDRXS=3. In this form, eDRX will be disabled and data for all parameters in AT+CEDRXS will be removed or, if available, set to the default values.

The read command returns the current settings for each defined value of <AcT-type>.

The test command returns the supported <mode>s and the value ranges for the access technology and the requested eDRX value as compound values.

Please refer to **Chapter 6** for possible <err> values.

AT+CEDRXS eDRX Setting	
Test Command AT+CEDRXS=?	Response +CEDRXS: (list of supported <mode>s),(list of supported <AcT-type>s),(list of supported <Requested_eDRX_value>s) OK
Read Command AT+CEDRXS?	Response +CEDRXS: <AcT-type>,<Requested_eDRX_value> [+CEDRXS: <AcT-type>,<Requested_eDRX_value>] [...] OK
Write Command AT+CEDRXS=<mode>[,<AcT-type>[,<Requested_eDRX_value>]]	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode>	Integer type. Disable or enable the use of eDRX in the UE. This parameter is applicable to all specified types of access technology, i.e. the most recent setting of <mode> will take effect for all specified values of <AcT-type>.
0	Disable the use of eDRX
1	Enable the use of eDRX
2	Enable the use of eDRX and enable the unsolicited result code "+CEDRXP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Pa

	ging_time_window>]]]]”
3	Disable the use of eDRX and discard all parameters for eDRX or, if available, reset to default values.
<AcT-type>	Integer type. Indicates the type of access technology. AT+CEDRXS? is used to specify the relationship between the type of access technology and the requested eDRX value.
0	Access technology is not using eDRX. This parameter value is only used in the unsolicited result code.
5	E-UTRAN (NB-S1 mode)
<Requested_eDRX_value>	String type. Half a byte in a 4-bit format. NB-S1 mode.
	bit
	4 3 2 1 E-UTRAN eDRX cycle length duration
	0 0 1 0 20.48 seconds
	0 0 1 1 40.96 seconds
	0 1 0 1 81.92 seconds
	1 0 0 1 163.84 seconds
	1 0 1 0 327.68 seconds
	1 0 1 1 655.36 seconds
	1 1 0 0 1310.72 seconds
	1 1 0 1 2621.44 seconds
	1 1 1 0 5242.88 seconds
	1 1 1 1 10485.76 seconds
<NW-provided_eDRX_value>	String type. Half a byte in a 4-bit format. NB-S1 mode.
	bit
	4 3 2 1 E-UTRAN eDRX cycle length duration
	0 0 1 0 20.48 seconds
	0 0 1 1 40.96 seconds
	0 1 0 1 81.,92 seconds
	1 0 0 1 163.84 seconds
	1 0 1 0 327.68 seconds
	1 0 1 1 655.36 seconds
	1 1 0 0 1310.72 seconds
	1 1 0 1 2621.44 seconds
	1 1 1 0 5242.88 seconds
	1 1 1 1 10485.76 seconds
<Paging_time_window>	String type. Half a byte in a 4 bit format. NB-S1 mode.
	bit
	4 3 2 1 Paging Time Window length
	0 0 0 0 2.56 seconds
	0 0 0 1 5.12 seconds
	0 0 1 0 7.68 seconds
	0 0 1 1 10.24 seconds
	0 1 0 0 12.8 seconds
	0 1 0 1 15.36 seconds

0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds
1	1	1	1	40.96 seconds

Example

```
AT+CEDRXS=1,5,"0101"
```

```
OK
```

```
AT+CEDRXS?
```

```
+CEDRXS: 5,"0101"
```

```
OK
```

```
AT+CEDRXS=?
```

```
+CEDRXS: (0-3),(5),("0000"-"1111")
```

```
OK
```

3.26. AT+CEDRXRDP eDRX Read Dynamic Parameters

The execution command returns <AcT-type>, <Requested_eDRX_value>, <NW-provided_eDRX_value> and <Paging_time_window> if eDRX is used for the cell that the MS is currently registered to.

If the cell that the MS is currently registered to is not using eDRX, AcT-type=0 is returned.

Please refer to **Chapter 6** for possible <err> values.

AT+CEDRXRDP eDRX Read Dynamic Parameters

Test Command	Response
AT+CEDRXRDP=?	OK
Execution Command	Response
AT+CEDRXRDP	+CEDRXRDP: <AcT-type>[,<Requested_eDRX_value>[,<NW-provided_eDRX_value>[,<Paging_time_window>]]]

	<p>OK</p> <p>If there is any error, response:</p> <p>ERROR</p> <p>Or</p> <p>+CME ERROR: <err></p>
Maximum Response Time	300ms

Parameter

<AcT-type>	<p>Integer type. The type of access technology. AT+CEDRXS? is used to specify the relationship between the type of access technology and the requested eDRX value.</p> <p>0 Access technology is not using eDRX. This parameter value is only used in the unsolicited result code</p> <p>5 E-UTRAN (NB-S1 mode)</p>																																																							
<Requested_eDRX_value>	<p>String type. Half a byte in a 4-bit format.</p> <p>bit</p> <table border="0"> <tr> <td>4</td><td>3</td><td>2</td><td>1</td><td>E-UTRAN eDRX cycle length duration</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>0</td><td>20.48 seconds</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>1</td><td>40.96 seconds</td> </tr> <tr> <td>0</td><td>1</td><td>0</td><td>1</td><td>81.92 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>0</td><td>1</td><td>163.84 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>0</td><td>327.68 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>1</td><td>655.36 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>0</td><td>1310.72 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>1</td><td>2621.44 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>0</td><td>5242.88 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>1</td><td>10485.76 seconds</td> </tr> </table>	4	3	2	1	E-UTRAN eDRX cycle length duration	0	0	1	0	20.48 seconds	0	0	1	1	40.96 seconds	0	1	0	1	81.92 seconds	1	0	0	1	163.84 seconds	1	0	1	0	327.68 seconds	1	0	1	1	655.36 seconds	1	1	0	0	1310.72 seconds	1	1	0	1	2621.44 seconds	1	1	1	0	5242.88 seconds	1	1	1	1	10485.76 seconds
4	3	2	1	E-UTRAN eDRX cycle length duration																																																				
0	0	1	0	20.48 seconds																																																				
0	0	1	1	40.96 seconds																																																				
0	1	0	1	81.92 seconds																																																				
1	0	0	1	163.84 seconds																																																				
1	0	1	0	327.68 seconds																																																				
1	0	1	1	655.36 seconds																																																				
1	1	0	0	1310.72 seconds																																																				
1	1	0	1	2621.44 seconds																																																				
1	1	1	0	5242.88 seconds																																																				
1	1	1	1	10485.76 seconds																																																				
<NW-provided_eDRX_value>	<p>String type. Half a byte in a 4-bit format.</p> <p>bit</p> <table border="0"> <tr> <td>4</td><td>3</td><td>2</td><td>1</td><td>E-UTRAN eDRX cycle length duration</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>0</td><td>20.48 seconds</td> </tr> <tr> <td>0</td><td>0</td><td>1</td><td>1</td><td>40.96 seconds</td> </tr> <tr> <td>0</td><td>1</td><td>0</td><td>1</td><td>81.92 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>0</td><td>1</td><td>163.84 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>0</td><td>327.68 seconds</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>1</td><td>655.36 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>0</td><td>1310.72 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>0</td><td>1</td><td>2621.44 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>0</td><td>5242.88 seconds</td> </tr> <tr> <td>1</td><td>1</td><td>1</td><td>1</td><td>10485.76 seconds</td> </tr> </table>	4	3	2	1	E-UTRAN eDRX cycle length duration	0	0	1	0	20.48 seconds	0	0	1	1	40.96 seconds	0	1	0	1	81.92 seconds	1	0	0	1	163.84 seconds	1	0	1	0	327.68 seconds	1	0	1	1	655.36 seconds	1	1	0	0	1310.72 seconds	1	1	0	1	2621.44 seconds	1	1	1	0	5242.88 seconds	1	1	1	1	10485.76 seconds
4	3	2	1	E-UTRAN eDRX cycle length duration																																																				
0	0	1	0	20.48 seconds																																																				
0	0	1	1	40.96 seconds																																																				
0	1	0	1	81.92 seconds																																																				
1	0	0	1	163.84 seconds																																																				
1	0	1	0	327.68 seconds																																																				
1	0	1	1	655.36 seconds																																																				
1	1	0	0	1310.72 seconds																																																				
1	1	0	1	2621.44 seconds																																																				
1	1	1	0	5242.88 seconds																																																				
1	1	1	1	10485.76 seconds																																																				
<Paging_time_window>	<p>String type. Half a byte in a 4-bit format.</p> <p>bit</p>																																																							

4	3	2	1	Paging Time Window length
0	0	0	0	2.56 seconds
0	0	0	1	5.12 seconds
0	0	1	0	7.68 seconds
0	0	1	1	10.24 seconds
0	1	0	0	12.8 seconds
0	1	0	1	15.36 seconds
0	1	1	0	17.92 seconds
0	1	1	1	20.48 seconds
1	0	0	0	23.04 seconds
1	0	0	1	25.6 seconds
1	0	1	0	28.16 seconds
1	0	1	1	30.72 seconds
1	1	0	0	33.28 seconds
1	1	0	1	35.84 seconds
1	1	1	0	38.4 seconds

Example

```

AT+CEDRXRDP
+CEDRXRDP: 5,"0010","1110","0101"

OK
AT+CEDRXRDP=?
OK
    
```

3.27. AT+CTZR Time Zone Reporting

This write command enables/disables the time zone change event reporting. If the reporting is enabled the MT returns the unsolicited result code “+CTZV: <tz>” whenever the time zone is changed. Please refer to **Chapter 6** for possible <err> values.

AT+CTZR Time Zone Reporting

Test Command AT+CTZR=?	Response +CTZR: (list of supported <onoff>s) OK
Read Command AT+CTZR?	Response +CTZR: <onoff> OK

	<p>If there is any error, response: ERROR Or +CME ERROR: <err></p>
<p>Write Command AT+CTZR=<onoff></p>	<p>Response OK</p> <p>If there is any error, response: ERROR Or +CME ERROR: <err></p>
<p>Maximum Response Time</p>	<p>300ms</p>

Parameter

<onoff>	<p>0 Disable time zone change event reporting</p> <p>1 Enable time zone change event reporting by unsolicited result code "+CTZV: <tz>".</p>
<tz>	<p>String type. Represents the sum of the local time zone (difference between the local time and GMT expressed in quarters of an hour) plus daylight saving time. The format is "±zz", expressed as a fixed width, two digits integer with the range -48 ~ +56. To maintain a fixed width, numbers in the range -9 ~ +9 are expressed with a leading zero, e.g. "-09", "+00" and "+09".</p>

Example

```

AT+CTZR=?
+CCTZR: (0,1)

OK
AT+CTZR=0
OK
AT+CTZR?
+CCTZR: 0

OK

```

3.28. AT+CIPCA Initial PDP Context Activation

The write command controls whether the UE is attached to E-UTRAN with or without a PDN connection.

The value of `<n>=3` applies to E-UTRAN RATs. Changing `<n>` will never cause a PDP context deactivation.

For `<AttachWithoutPDN>=1`, the EPS attach is performed without a PDN connection.

The read command returns the current setting of the command.

The test command returns values supported as a compound value.

Please refer to **Chapter 6** for possible `<err>` values.

AT+CIPCA Initial PDP Context Activation

Test Command AT+CIPCA=?	Response +CIPCA: (list of supported <code><n>s</code>),(list of supported <code><AttachWithoutPDN>s</code>) OK
Read Command AT+CIPCA?	Response +CIPCA: <code><n></code> [, <code><AttachWithoutPDN></code>] OK If there is any error, response: ERROR or +CME ERROR: <err>
Write Command AT+CIPCA=<n> [, <code><AttachWithoutPDN></code>] >	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<code><n></code>	Integer type. Activation of PDP context upon attaching. <u>3</u> No change in current setting
<code><AttachWithoutPDN></code>	Integer type. EPS attach with or without PDN connection. <u>0</u> EPS attach with PDN connection <u>1</u> EPS attach without PDN connection

NOTE

For this command, the term roaming corresponds to being registered on a VPLMN which is not equivalent to HPLMN or EHPLMN.

Example

```
AT+CIPCA=3,1
OK
AT+CIPCA?
+CIPCA: 3,1

OK
AT+CIPCA=?
+CIPCA: (3),(0,1)

OK
```

3.29. AT+CCIOTOPT CloT Optimization Configuration

The write command controls which CloT EPS optimizations the UE indicates as supported and preferred in the ATTACH REQUEST and TRACKING AREA UPDATE REQUEST messages. The command also allows reporting of the CloT EPS optimizations that are supported by the network. UE supporting CloT functionality support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see *3GPP TS 24.301, sub-clause 9.9.3.34*). Based on the application characteristics the UE may prefer to be registered for control plane CloT EPS optimization or for user plane CloT EPS optimization (see *3GPP TS 24.301, sub-clause 9.9.3.0B*).

Further the network may support control plane CloT EPS optimization or user plane CloT EPS optimization or both (see *3GPP TS 24.301, sub-clause 9.9.3.12A*).

The write command is used also to control the unsolicited result code "+CCIOTOPTI". An unsolicited result code "+CCIOTOPTI: <supported_Network_opt>" is used indicate the supported CloT EPS optimization by the network.

The read command returns the current settings for supported and preferred CloT EPS optimization and the current status of unsolicited result code "+CCIOTOPTI".

Please refer to **Chapter 6** for possible <err> values.

AT+CCIOTOPT CloT Optimization Configuration

Test Command AT+CCIOTOPT=?	Response +CCIOTOPT: (list of supported <n>s),(list of supported <supported_UE_opt>s),(list of supported <preferred_UE_opt>s) OK
Read Command AT+CCIOTOPT?	Response +CCIOTOPT: <n>,<supported_UE_opt>,<preferred_UE_opt> OK
Write Command AT+CCIOTOPT=<n>[,<supported_UE_opt>[,<preferred_UE_opt>]]	Response When <n>=0 or 2: OK When <n>=1: OK +CCIOTOPTI: <supported_Network_opt> If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<n>	Integer type. Enable/disable reporting of unsolicited result code "+CCIOTOPTI". <u>0</u> Disable reporting 1 Enable reporting 2 Disable reporting and reset the parameters for CloT EPS optimization to the default values
<supported_UE_opt>	Integer type. Indicates the UE's support for CloT EPS optimizations. <u>1</u> Support control plane CloT EPS optimization 2 Support user plane CloT EPS optimization 3 Support both control plane and user plane CloT EPS optimizations
<preferred_UE_opt>	Integer type. Indicates the UE's preference for CloT EPS optimizations. 0 No preference <u>1</u> Preference for control plane CloT EPS optimization

<supported_Network_opt>	<p>2 Preference for user plane CloT EPS optimization</p> <p>Integer type. Indicates the network's support for CloT EPS optimizations.</p> <p>0 Not support</p> <p>1 Support control plane CloT EPS optimization</p> <p>2 Support user plane CloT EPS optimization</p> <p>3 Support both control plane and user plane CloT EPS optimizations</p>
--------------------------------------	---

3.30. AT+CGAPNRC APN Rate Control

The write command returns the APN rate control parameters (see *3GPP TS 24.008 [8]*) associated to the provided context identifier <cid>.

If the parameter <cid> is omitted, the APN rate control parameters for all active PDP contexts are returned.

The test command returns a list of <cid>s associated with secondary and non-secondary active PDP contexts.

Please refer to **Chapter 6** for possible <err> values.

AT+CGAPNRC APN Rate Control	
Test Command AT+CGAPNRC=?	<p>Response</p> <p>+CGAPNRC: (list of <cid>s associated with active contexts)</p> <p>OK</p>
Write Command AT+CGAPNRC=<cid>	<p>Response</p> <p>+CGAPNRC: <cid>[,<Additional_exception_reports>[,<Uplink_time_unit>[,<Maximum_uplink_rate>]]]</p> <p>[+CGAPNRC: <cid>[,<Additional_exception_reports>[,<Uplink_time_unit>[,<Maximum_uplink_rate>]]]</p> <p>[...]</p> <p>OK</p> <p>If there is any error, response:</p> <p>ERROR</p> <p>or</p> <p>+CME ERROR: <err></p>
Maximum Response Time	300ms

Parameter

<cid>	Integer type. Specifies a particular PDP context definition (see the AT+CGDCONT command).
<Additional_exception_reports>	Integer type. Indicates whether or not additional exception reports are allowed to be sent when the maximum uplink rate is reached. This refers to bit 4 of octet 1 of the APN rate control parameters IE as specified in <i>3GPP TS 24.008 [8] subclause 10.5.6.3.2</i> . 0 Additional exception reports at maximum rate reached are not allowed to be sent. 1 Additional exception reports at maximum rate reached are allowed to be sent.
<Uplink_time_unit>	Integer type. Specifies the time unit to be used for the maximum uplink rate. This refers to bits 1 to 3 of octet 1 of the APN rate control parameters IE as specified in <i>3GPP TS 24.008 [8] subclause 10.5.6.3.2</i> . 0 Unrestricted 1 Minute 2 Hour 3 Day 4 Week
<Maximum_uplink_rate>	Integer type. Specifies the maximum number of messages the UE is restricted to send per uplink time unit. This refers to octet 2 to 4 of the APN rate control parameters IE as specified in <i>3GPP TS 24.008 [8] subclause 10.5.6.3.2</i> .

3.31. AT+CEER Extended Error Report

The execution command causes the TA to return one or more lines of information text <report>, determined by the MT manufacturer, which should offer the user of the TA an extended report of the reason for the following errors:

- The failure in the last call release;
- The failure in the last unsuccessful PDP context activation;
- The failure in the PDP context deactivation.

Typically, the text will consist of a single line containing the cause information given by network in textual format.

AT+CEER Extended Error Report

Test Command AT+CEER=?	Response OK
Execution Command AT+CEER	Response +CEER: <report> OK
Maximum Response Time	300ms

Parameter

<report> Extended error report. The total number of characters, including line terminators, in the information text shall not exceed 2041 characters. The text shall not contain the sequence 0<CR> or OK<CR>.

Example

```
AT+CEER
+CEER: EMM_CAUSE_EPS_AND_NON_EPS_SERVICES_NOT_ALLOWED

OK
AT+CEER=?
OK
```

4 General Commands

4.1. AT+QGACT Activate/Deactivate a PDN Context

Activate or deactivate a specified PDN context.

There are three kinds of responses for both the activation requirement and the deactivation requirement. If the PDN context is active/inactive, "+QGACT: <cid>,<type>,<result>[,<activated_pdp_type>] OK" is returned immediately for activation/deactivation requirement. If not activated/deactivated, "+QGACT: <cid> OK" is returned first and the URC "+QGACT: <cid>,<type>,<result>[,<activated_pdp_type>]" is reported for the activation/deactivation result later. If any error occurs, such as invalid parameter(s), "ERROR" is returned immediately. In any case, <activated_pdp_type> only exists for the activation requirement.

Besides, URC "+QGACT: <cid>,<type>" is reported when passive deactivation occurs.

For the activation requirement, the format of the write command is "AT+QGACT=<op>,<pdp_type>,<apn>,<user_name>,<pwd>[,<bearer_type>[,<sim_id>]]", while for the deactivation requirement, the format is "+QGACT=<op>,<cid>". For the purpose of normalization, the format of QGACT is: "+QGACT=<op>,<pdp_type/cid>[,<apn>,<user_name>,<pwd>[,<bearer_type>[,<sim_id>]]]".

Please refer to **Chapter 6** for possible <err> values.

AT+QGACT Activate/Deactivate a PDN Context

Write Command

AT+QGACT=<op>,<pdp_type/cid>,<apn>[,<user_name>,<pwd>[,<bearer_type>[,<sim_id>]]]

Response

If the PDN context is already in active/inactive state:

+QGACT: <cid>,<type>,<result>[,<activated_pdp_type>]

OK

If the PDN context is not in active/inactive state:

+QGACT: <cid>

OK

+QGACT: <cid>,<type>,<result>[,<activated_pdp_type>]

	If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<op>	Integer type. Deactivation/Activation requirement. 0 Deactivation requirement 1 Activation requirement
<pdp_type>	Integer type. PDP type to be activated. 1 IPv4 2 IPv6 3 IPv4v6 4 Non-IP
<cid>	Integer type. It is a numeric parameter specifying a particular PDP context.
<apn>	String type. It is the access point name which is mandatory for the activation requirement and should be omitted for the deactivation requirement.
<user_name>	String type. It is the username for access to the IP network which is mandatory for the activation requirement and should be omitted for the deactivation requirement.
<pwd>	String type. It is the password for access to the IP network which is mandatory for the activation requirement and should be omitted for the deactivation requirement.
<bearer_type>	Integer type. It is the type of bearer wanted to activate which is optional for the activation requirement and should be omitted for the deactivation requirement. 1 NB-IoT (Only NB-IoT is supported currently)
<sim_id>	Integer type. It is the ID of the USIM Card wanted to use which is optional for the activation requirement and should be omitted for the deactivation requirement. 1 USIM Card 1 (Only USIM Card 1 is supported currently).
<type>	Integer type. 0 Result/URC for deactivation requirement 1 Result/URC for activation requirement 2 URC for passive deactivation
<result>	Integer type. 0 Failure 1 Successful
<activated_pdp_type>	Integer type. It is the PDP type actually activated. 1 IPv4

2	IPv6
3	IPv4v6
4	Non-IP

NOTE

The default PDN (<cid>=1) will be established automatically after the module is registered on network.

Example

```

AT+QGACT=1,1,"apn","","" //Activate a PDN context
+QGACT: 1
OK //Return "OK" immediately for no error
+QGACT: 1,1,1,1 //Notify activation result via URC

AT+QGACT=0,1 //Deactivate a PDN context
+QGACT: 1
OK //Return "OK" immediately for no error
+QGACT: 1,0,1 //Notify deactivation result via URC
    
```

4.2. AT+QBAND Get and Set Mobile Operation Band

The command is used to get the currently registered band or set the bands to be locked. Please refer to **Chapter 6** for possible <err> values.

AT+QBAND Get and Set Mobile Operation Band

Test Command AT+QBAND=?	Response +QBAND: (list of supported <band number>s)[,(list of supported <Operating Bands>s)] OK
Read Command AT+QBAND?	Response +QBAND: <Operating Band> OK

	<p>If there is any error, response: ERROR or +CME ERROR: <err></p>
<p>Write Command AT+QBAND=<band number>[,<band>[,<band>[,...]]]</p>	<p>Response OK</p> <p>If there is any error, response: ERROR or +CME ERROR: <err></p>
Maximum Response Time	300ms

Parameter

<band number>	<p>Integer value indicating preferred band number to be searched</p> <p>0 All bands</p> <p>1-15 Number of bands to be locked</p>
<band>	<p>Integer value indicating currently preferred NB-IoT band to be searched</p> <p>Valid values: 1, 2, 3, 5, 8, 12, 13, 17, 18, 19, 20, 25, 26, 28, 66</p>
<Operating Band>	<p>Integer value indicating the band(s) being used.</p> <p>Valid values: 1, 2, 3, 5, 8, 12, 13, 17, 18, 19, 20, 25, 26, 28, 66</p>

Example

```

AT+QBAND=? //Query the list of supported bands
+QBAND: (0-15),(1,2,3,5,8,12,13,17,18,19,20,25,26,28,66)

OK
AT+QBAND=1,5 //Sets the band to be used

OK

AT+QBAND? //Query the band being used
+QBAND: 5

OK

```

NOTE

Full-band is supported on NBR01A02 and later versions.

4.3. AT+QRST Automatically Reset

This command is used to reset the module immediately.

Please refer to **Chapter 6** for possible <err> values.

AT+QRST Automatically Reset

Test Command AT+QRST=?	Response +QRST: (list of supported <mode>s) OK
Write Command AT+QRST=<mode>	Response Automatically Reset immediately If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode> 1 Automatically reset immediately

4.4. AT+QSPCHSC Set Scrambling Algorithm

This command is used to select new or old scrambling code. This is because the scrambling code has been updated by 3GPP, and UE needs to select the correct code for network.

Please refer to **Chapter 6** for possible <err> values.

AT+QSPCHSC Set Scrambling Algorithm

Test Command AT+QSPCHSC=?	Response +QSPCHSC: (list of supported <mode>s) OK
Read Command AT+QSPCHSC?	Response +QSPCHSC: <mode> OK
Write Command AT+QSPCHSC=<mode>	Response OK If there is any error, response : ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode>	Integer
0	Old algorithm
1	New algorithm

4.5. AT+QLOCKF Lock NB-IoT Frequency

This command is used to lock UE to specific frequency and optionally Cell ID.

Please refer to **Chapter 6** for possible <err> values.

AT+QLOCKF Lock NB-IoT Frequency

Test Command AT+QLOCKF=?	Response OK
Read command AT+QLOCKF?	Response OK
Write Command AT+QLOCKF=<mode>[,<earfcn>,<ear fcn_offset>[,<pci>]]	Response OK If there is any error, response :

	ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode>	Integer value indicating activate/remove lock 0 Remove lock 1 Activate lock
<earfcn>	Integer value indicating requested EARFCN on which to lock. Range: 0-262143. Value 0 indicates to remove any lock for EARFCN and Cell.
<earfcn_offset>	Integer value indicating requested EARFCN offset 0 Offset of -2 1 Offset of -1 2 Offset of -0.5 3 Offset of 0 4 Offset of 1
<pci>	Integer value indicating the physical cell ID. Range: 0-503.

4.6. AT+QCSEARFCN Clear NB-IoT Stored EARFCN List

This command is used to clear stored EARFCN list for the UE.

Please refer to **Chapter 6** for possible <err> values.

AT+ QCSEARFCN Clear NB-IoT Stored EARFCN List	
Execution Command AT+QCSEARFCN	Response +QCSEARFCN: <status> OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<status>	Integer value indicating the EARFCN has been cleared
0	Successful
2	Failure
3	Not found

Example

```
AT+QCSEARFCN
+QCSEARFCN: 0

OK
```

4.7. AT+QCGDEFCONT Set Default PSD Connection Settings

This command is used to set the PSD connection settings for PDN connection on power-up. When attaching to the NB-IoT network on power-on, a PDN connection setup must be performed. In order to allow this to happen, PDN connection settings must be stored in NVRAM, thus making it to be used by the modem during the attach procedure.

Please refer to **Chapter 6** for possible <err> values.

AT+QCGDEFCONT Set Default PSD Connection Settings

Test Command AT+QCGDEFCONT=?	Response +QCGDEFCONT: (list of supported <PDP_type>s) OK
Read Command AT+QCGDEFCONT?	Response +QCGDEFCONT: <PDP_type>,<APN>,<username>,<password> OK
Write Command AT+QCGDEFCONT=<PDP_type>[,<APN>[,<username>[,<password>]]]	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<PDP_type>	String type. Specifies the type of packet data protocol: IP Internet Protocol (IETF STD 5) IPV6 Internet Protocol version 6 (IETF RFC 2460) IPV4V6 Dual IP stack ,UE capability (see 3GPP TS 24.301) Non-IP Transfer of Non-IP data to external packet network (see 3GPP TS 24.301)
<APN>	String type. a logical name that is used to select the GGSN or the external packet data network. If the value is null or omitted, then the subscription value will be requested.
<user_name>	String type. It is the username for access to the IP network which is mandatory for the activation requirement and should be omitted for the deactivation requirement.
<password>	String type. It is the password for access to the IP network which is mandatory for the activation requirement and should be omitted for the deactivation requirement.

NOTE

Need to reboot the module to take effect the new setting for default PDN connection.

4.8. AT+QNBIOTRAI NB-IoT Release Assistance Indication

This command is used to set the NB-IoT release assistance indication as follows:

- No information available
- TE will send only 1 UL packet and no DL packet is expected
- TE will send only 1 UL packet and only 1 DL packet is expected

Please refer to **Chapter 6** for possible <err> values.

AT+QNBIOTRAI NB-IoT Release Assistance Indication

Test Command AT+QNBIOTRAI=?	Response +QNBIOTRAI: (list of supported <rai>s) OK
Read Command AT+QNBIOTRAI?	Response +QNBIOTRAI: <rai> OK
Write Command AT+QNBIOTRAI=<rai>	Response OK

	If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<rai>	Integer type. Specifies release assistance information
<u>0</u>	No information available (or none of the other options apply)
1	TE will send only 1 UL packet and no DL packets expected
2	TE will send only 1 UL packet and only 1 DL packet expected

4.9. AT+QNBIOTEVENT Enable/Disable NB-IoT Related Event Report

This command is used to enable/disable the specific event report.

Please refer to **Chapter 6** for possible <err> values.

AT+QNBIOTEVENT Enable/Disable NB-IoT Related Event Report

Test Command AT+QNBIOTEVENT=?	Response OK
Read Command AT+QNBIOTEVENT?	Response OK
Write Command AT+QNBIOTEVENT=<enable>,<event> >	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<enable>	Integer type.
<u>0</u>	Disable the indication of specific event
1	Enable the indication of specific event by unsolicited result code “+QNBIOTEVENT: <event_value>”

<event>	Integer type. Indicate the report event 1 PSM state
<event_value>	String type. When event is PSM ENTER PSM/EXIT PSM

4.10. AT+QATWAKEUP Enable/Disable Deep Sleep Wakeup Indication

This command is used to enable/disable an unsolicited result code on a channel that indicates when the modem is fully woken up after a deep sleep.

Please refer to **Chapter 6** for possible <err> values.

AT+QATWAKEUP Enable/Disable Deep Sleep Wakeup Indication

Test Command AT+QATWAKEUP=?	Response +QATWAKEUP: (list of supported <enable>s) OK
Read Command AT+QATWAKEUP?	Response +QATWAKEUP: <enable> OK
Write Command AT+QATWAKEUP=<enable>	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<enable>	Integer type. 0 Disable indication on this channel when modem wakes up from deep sleep 1 Enable indication on this channel when modem wakes up from deep sleep
-----------------------	--

Example

```
AT+QATWAKEUP=1 //Enable wakeup indication

OK
(Modem goes into deep sleep mode)
(Modem is woken up from deep sleep mode)

+QATWAKEUP //The modem has been fully woken up and ready to receive AT commands/data
```

4.11. AT+QENG Engineering Mode

This command is used to query current modem status information for serving cell and current network status in Engineering Mode. Please refer to **Chapter 6** for possible <err> values.

AT+QENG Engineering Mode

Test Command	Response
AT+QENG=?	+QENG: (list of supported <mode>s) OK
Write Command AT+QENG=<mode>	When <mode>=0: Response +QENG: 0,<sc_earfcn>,<sc_earfcn_offset>,<sc_pci>,<sc_cellid>,<sc_rsrp>,<sc_rsrq>,<sc_rssi>,<sc_snr>,<sc_band>,<sc_tac>,<sc_ecl>,<sc_tx_pwr> [+QENG: 1,<nc_earfcn>,<nc_earfcn_offset>,<nc_pci>,<nc_rsrp>,...] OK When <mode>=1: Response +QENG: 2,<RLC_UL_BLER>,<RLC_DL_BLER>,<MAC_UL_BLER>,<MAC_DL_BLER>,<MAC_UL_total_bytes>,<MAC_DL_total_bytes>,<MAC_UL_total_HARQ_TX>,<MAC_DL_total_HARQ_TX>,<MAC_UL_HARQ_re_TX>,<MAC_DL_HARQ_re_TX>,<RLC_UL_tput>,<RLC_DL_tput>,<MAC_UL_tput>,<MAC_DL_tput> OK If there is any error, response:

	ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<mode>	Integer value indicating requested engineering information. 0 Display radio information for serving and neighbor cells 1 Display data transfer information only if modem in RRC-CONNECTED state
<sc_earfcn>	Integer value indicating the EARFCN for serving cell. Range: 0-262143.
<sc_earfcn_offset>	Integer value indicating the EARFCN offset for serving cell: 0 Offset of -2 1 Offset of -1 2 Offset of -0.5 3 Offset of 0 4 Offset of 1
<sc_pci>	Integer value indicating the serving cell physical cell ID. Range: 0-503.
<sc_cellid>	String type. Four-byte (28-bit) cell ID in hexadecimal format for serving cell.
<sc_rsrp>	Signed integer indicating serving cell RSRP value in units of dBm (can be negative value). Available only in RRC-IDLE state.
<sc_rsrq>	Signed integer indicating serving cell RSRQ value in units of dB (can be negative value). Available only in RRC-IDLE state.
<sc_rssi>	Signed integer indicating serving cell RSSI value in units of dBm (can be negative value). Available only in RRC-IDLE state.
<sc_snr>	Signed integer value. Last SNR value for serving cell in units of dB. Available only in RRC-IDLE state.
<sc_band>	Integer value. Current serving cell band.
<sc_tac>	String type. Two-byte tracking area code (TAC) in hexadecimal format (e.g. "00C3" equals 195 in decimal).
<sc_ecl>	Integer value. Last Enhanced Coverage Level (ECL) value for serving cell. Range: 0-2.
<sc_tx_pwr>	Signed integer value indicating current UE transmit power. Units of cBm Centibels relative to one milliwatt (can be negative value).
<nc_earfcn >	Integer value indicating the EARFCN for neighbor cell. Range: 0-262143.
<nc_earfcn_offset >	Integer value indicating the EARFCN offset for neighbor cell: 0 Offset of -2 1 Offset of -1 2 Offset of -0.5 3 Offset of 0 4 Offset of 1
<nc_pci >	Integer value indicating the neighbor cell physical cell ID. Range: 0-503.
<nc_rsrp>	Signed integer indicating neighbor cell RSRP value in units of dBm (can be

-
- negative value).
- <RLC_UL_BLER >** Integer value. Represented in % value (range 0 to 100). UL block error rate (as per IRQ) in RLC. Calculated over all established RLC AM radio bearers. Calculated from the beginning of successfully established/resumed RRC connection or since previous AT+QENG query with <mode>=1, whichever is later. Only valid in RRC-CONNECTED state.
- < RLC_DL_BLER >** Integer value. Represented in % value (range 0 to 100). DL block error rate (as per ARQ) in RLC. Calculated over all established RLC AM radio bearers. Calculated from the beginning of successfully established/resumed RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state.
- < MAC_UL_BLER >** Integer value. Represented in % value (range 0 to 100). UL block error rate (as per HARQ) in MAC for UL-SCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state.
- <MAC_DL_BLER>** Integer value. Represented in % value (range 0 to 100). DL block error rate (as per HARQ) in MAC for DL-SCH, excluding BCCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state.
- <MAC_UL_total_bytes>** Integer value. Total number of transport block bytes (re)transmitted on UL-SCH. Calculated for UL-SCH over all HARQ transmissions and retransmissions. Calculated from the beginning of successfully established / resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: bytes.
- <MAC_DL_total_bytes>** Integer value. Total number of transport block bytes (re)transmitted on DL-SCH, excluding BCCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: bytes.
- <MAC_UL_total_HARQ_TX>** Integer value. Total number of HARQ (re)transmissions for transport blocks on UL-SCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: (re)transmissions.
- <MAC_DL_total_HARQ_TX>** Integer value. Total number of HARQ (re)transmissions for transport blocks on DL-SCH, excluding BCCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRCONNECTED state. Unit: (re)transmissions
- <MAC_UL_HARQ_re_TX>** Integer value. Number of HARQ retransmissions for transport blocks on UL-SCH. Calculated from the beginning of successfully established
-

	/resumed / re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: retransmissions
<MAC_DL_HARQ_re_TX>	Integer value. Number of HARQ retransmissions for transport blocks on DL-SCH, excluding BCCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRCCONNECTED state. Unit: retransmissions.
<RLC_UL_tput>	Integer value. RLC uplink throughput. Calculated over all established RLC AM radio bearers. Calculated from the beginning of successfully established/resumed RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: kbits/s.
<RLC_DL_tput>	Integer value. RLC downlink throughput. Calculated over all established RLC AM radio bearers. Calculated from the beginning of successfully established/resumed RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: kbits/s.
<MAC_UL_tput>	Integer value. UL throughput in MAC for UL-SCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: kbits/s.
<MAC_DL_tput>	Integer value. DL throughput in MAC for DL-SCH, excluding BCCH. Calculated from the beginning of successfully established/resumed/re-established RRC connection, or since previous AT+QENG query with <mode>=1, whichever is later. Available only in RRC-CONNECTED state. Unit: kbits/s.

4.12. AT+QCCID USIM Card Identification

The commands read the ICCID of the USIM card. If no USIM card is present, or the USIM card is unreadable, no data is returned.

Please refer to **Chapter 6** for possible <err> values.

AT+QICCID USIM Card Identification	
Execution Command	Response
AT+QCCID	+QCCID: <ICCID>
	OK
Maximum Response Time	300ms

Parameter

<ICCID> USIM card identification number

Example

```
AT+QCCID
+QCCID: 89860317482035195410

OK
```

4.13. AT+QPOWD Power off the Module

The commands is used to power off the module.

Please refer to **Chapter 6** for possible <err> values.

AT+QPOWD Power off the Module

Read Command AT+QPOWD=?	Response +QPOWD: (0) OK
Write Command AT+QPOWD=<op>	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	1s

Parameter

<op> 0 Power off the module

Example

```
AT+QPOWD=0

OK
```

4.14. AT+QSCLK Configure Sleep Mode

The commands is used to configure UE sleep mode.

Please refer to **Chapter 6** for possible <err> values.

AT+QSCLK Configure Sleep Mode

Test Command AT+QSCLK=?	Response +QSCLK: (0-2) OK
Read Command AT+QSCLK?	Response +QSCLK: <n> OK
Write Command AT+QSCLK=<n>	Response OK If there is any error, response: ERROR or +CME ERROR: <err>
Maximum Response Time	300ms

Parameter

<n>	0	Disable Sleep Mode
	<u>1</u>	Enable light sleep and deep sleep, wakeup by PSM_EINT (Falling Edge)
	2	Enable light sleep only, wakeup by Main UART

Example

```
AT+QSCLK=1
OK
```

5 Examples

5.1. Network Attachment

The module currently only supports registering on network after power on automatically.

5.1.1. Manual Query of Network Attachment State

The following shows a simple example to automatically attach the network. Customers only need to query whether the module has attached to network by the following commands:

```
//Power on
F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized

//Configure the APN for initial attachment
//Once set, the parameters will be saved to NVRAM
//Take effect on restart or re-registration

AT+QCGDEFCONT="IP","spe.inetd.vodafone.nbiot"
OK

AT+QRST=1

F1: 0000 0000
V0: 0000 0000 [0001]
```

```
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized

AT+CFUN?
+CFUN:1 //Value is 1 (full functionality).

OK

AT+CIMI //Query the IMSI number.
460012345678969

OK

AT+CESQ //Query the signal strength.
+CESQ: 36,99,255,255,12,53

OK

AT+QENG=0 //Query the module's current network status.
+QENG: 0,2506,2,62,"6923252",-84,-10,-74,2,5,"69C9",0,90

OK

AT+CGATT? //Query whether the network is activated: 1 means attached to network
successfully, while 0 means has not been attached to network.
+CGATT:1

OK

AT+CEREG? //Query the network registration status: 1 means registered on network, while
2 means searching the network.
+CEREG:0,1

OK
```



```
AT+CSCON?           //Query the signal connection status: 1 means "Connected", while 0
                    //means "Idle".
+CSCON:0,1
OK
```

5.1.2. Automatic Network Attachment State Report via URC

The following shows a simple example to automatically attach the network. Customers do not need to query whether the module has attached to network always, the network attachment state will be reported via URC:

```
//Power on
F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK           //Successfully synchronized

//Configure the APN for initial attachment
//Once set, the parameters will be saved to NVRAM
//Take effect on restart or re-registration

AT+QCGDEFCONT="IP","spe.inetd.vodafone.nbiot"
OK

AT+QRST=1

F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM
```

```
//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized
AT+CFUN?
+CFUN:1 //Value is 1 (full functionality)

OK

AT+CIMI //Query the IMSI number.
460012345678969

OK
AT+CEREG=1 //Set to automatically report network registration status, that is, when the module is
registered on the network, a URC will be reported.

OK
AT+CSCON=1 //Set to automatically report signaling connection status, that is, when the module
is in connected or idle state, a URC will be reported.

OK
+CEREG:2 //Report the URC that the MT is currently trying to attach to or searching an
operator to register to.

+CSCON:1 //Report the URC that the MT is connected.

+CEREG:1 //Report the URC that the MT is registered.

AT+CESQ //Query the signal strength.
+CESQ: 36,99,255,255,12,53

OK

AT+QENG=0 //Query the module's status.
+QENG: 0,2506,2,62,"6923252",-84,-10,-74,2,5,"69C9",0,90

OK

AT+CGATT? //Query whether the network is activated: 1 means attached to network
successfully, while 0 means has not been attached to network.

+CGATT:1

OK
```

```
AT+CEREG? //Query the network registration status: 1 means registered on network, while 2 means searching the network.  
+CEREG:0,1  
OK  
AT+CSCON? //Query the signal connection status: 1 means "Connected", while 0 means "Idle".  
+CSCON:0,1  
OK
```

5.1.3. Automatic Network Attachment with Specified PLMN/EARFCN/PCI/Band

If the network attachment process takes a long time, then customers can try to specify PLMN or specify dedicated EARFCN or PCI or band to reduce the search time.

5.1.3.1. Attach to Network with Specified PLMN

The following shows a simple example for automatic network attachment with specified PLMN:

```
//Power on  
F1: 0000 0000  
V0: 0000 0000 [0001]  
00: 0006 000C  
01: 0000 0000  
U0: 0000 0001 [0000]  
T0: 0000 00B4  
Leaving the BROM  
  
//Auto-baud synchronization  
AT  
AT  
AT  
OK //Successfully synchronized  
  
//Configure the APN for initial attachment  
//Once set, the parameters will be saved to NVRAM  
//Take effect on restart or re-registration  
  
AT+QCGDEFCONT="IP","spe.inetd.vodafone.nbiot"  
OK
```

AT+QRST=1

F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization

AT

AT

AT

OK //Successfully synchronized

AT+CFUN?

+CFUN:1 //Value is 1 (full functionality).

OK

AT+CIMI //Query the IMSI number.

460012345678969

OK

AT+COPS=1,2,"46011" //Specify PLMN

OK

AT+CESQ //Query the signal strength.

+CESQ: 36,99,255,255,12,53

OK

AT+QENG=0 //Query the module status.

+QENG: 0,2506,2,62,"6923252",-84,-10,-74,2,5,"69C9",0,90

OK

AT+CGATT? //Query whether the network is activated: 1 means attached to network successfully, while 0 means has not been attached to network.

+CGATT:1

OK

AT+CEREG? //Query the network registration status: 1 means registered on network, while

```
2 means searching the network.
+CEREG:0,1

OK

AT+CSCON? //Query the signal connection status: 1 means "Connected", while 0
means "Idle".
+CSCON:0,1

OK
```

5.1.3.2. Attach to Network with Specified EARFCN/PCI

```
//Power on
F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized

//Configure the APN for initial attachment
//Once set, the parameters will be saved to NVRAM
//Take effect on restart or re-registration

AT+QCGDEFCONT="IP","spe.inetd.vodafone.nbiot"
OK

AT+QRST=1

F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
```

Leaving the BROM

//Auto-baud synchronization

AT

AT

AT

OK //Successfully synchronized

AT+CFUN?

+CFUN:1 //Value is 1 (full functionality).

OK

AT+CIMI //Query the IMSI number.

460012345678969

OK

AT+QLOCKF=1,2506,2,62 //Specify the EARFCN, offset and PCI.

OK

AT+CESQ //Query the signal strength.

+CESQ: 36,99,255,255,12,53

OK

AT+QENG=0 //Query the module status.

+QENG: 0,2506,2,62,"6923252",-84,-10,-74,2,5,"69C9",0,90

OK

AT+CGATT? //Query whether the network is activated: 1 means attached to network successfully, while 0 means has not been attached to network.

+CGATT:1

OK

AT+CEREG? //Query the network registration status: 1 means registered on network, while 2 means searching the network.

+CEREG:0,1

OK

AT+CSCON? //Query the signal connection status: 1 means "Connected", while 0 means "Idle".

```
+CSCON:0,1
```

```
OK
```

5.1.3.3. Attach to Network with Specified Band

```
//Power on
F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized

//Configure the APN for initial attachment
//Once set, the parameters will be saved to NVRAM
//Take effect on restart or re-registration

AT+QCGDEFCONT="IP","spe.inetd.vodafone.nbiot"
OK

AT+QRST=1

F1: 0000 0000
V0: 0000 0000 [0001]
00: 0006 000C
01: 0000 0000
U0: 0000 0001 [0000]
T0: 0000 00B4
Leaving the BROM

//Auto-baud synchronization
AT
AT
AT
OK //Successfully synchronized
```

AT+CFUN?

+CFUN:1 //Value is 1 (full functionality).

OK

AT+QBAND=?

//Query the list of supported bands

+QBAND:(1,2,3,5,8,11,12,13,17,18,19,20,21,25,26,28,31,66,70)

OK

AT+QBAND=1,5

//Sets the band to be used

OK

+IP: 10.170.235.216

AT+QBAND?

//Query the band being used

+QBAND:5

OK

6 Summary of <err> Codes

This chapter introduces the <err> codes related to BC66 module.

The error codes listed in the following two tables are compliant with the 3GPP specifications. Customers can refer to *3GPP TS 27.007 V13.5.0, sub-clause 9.2* for all possible <err> values.

Table 3: General <err> Codes (27.007)

Code of <err>	Description
3	Operation not allowed
4	Operation not supported
10	USIM not inserted
13	USIM failure
14	USIM busy
20	USIM memory full
23	Memory failure
24	Text string too long
25	Invalid characters in text string
30	No network service
31	Network timeout
32	Network not allowed - emergency calls only
50	Incorrect parameters
100	Unknown

The following error codes are specific ones for BC66 module.

Table 4: Specific <err> Codes

Code of <err>	Description
107	PSD services not allowed
111	PLMN not allowed
112	Location area not allowed
113	Roaming not allowed in this location area
132	Service option not supported
133	Requested service option not subscribed
149	PDP authentication failure
584	Combined service not allowed
588	Feature not supported
591	Implicitly detached
592	Insufficient resources
596	Invalid <cid> value
598	Mode value not in range
606	Low layer failure
607	Missing or unknown failure
615	Network failure
630	Profile (<cid>) not defined
631	Unspecified protocol error
639	Service type not yet available
675	PDN type IPv4 only allowed
676	PDN type IPv6 only allowed
692	EPS service not allowed
695	EPS tracking area not allowed

696	Roaming not allowed in TA
697	Roaming not allowed in PLMN
698	Not suitable cells in TA
700	ESM failure
703	Congestion
704	UE security capability mismatch
705	Security mode rejected
709	No EPS bearer context activated
765	Invalid input value
766	Unsupported value or mode
767	Operation failed
769	Unable to get control of required module
770	USIM Invalid – network reject
772	USIM powered down
840	No service state
841	In cell search state
842	ERRC is deactivated
843	In cell-reselection state
845	In re-establishment state
846	In PSM state
847	No data transfer in idle state

NOTE

AT+CME=<n> command disables (<n>=0) or enables (<n>=1) the use of final result code "+CME ERROR:<err>". When <n>=1, a limited set of error codes will be returned.

7 Appendix A Reference

Table 5: Terms and Abbreviations

Abbreviation	Description
3GPP	3 rd Generation Partnership Project
BCD	Binary Coded Decimal
GSM	Global System for Mobile Communications
IMSI	International Mobile Subscriber Identity
EARFCN	E-UTRA Absolute Radio Frequency Channel Number
eDRX	Extended Discontinuous Reception
EGPRS	Enhanced General Packet Radio Service
GERAN	GSM/EDGE Radio Access Network
GMT	Greenwich Mean Time
GPRS	General Packet Radio Service
HPLMN	Home Public Land Mobile Network
HSDPA	High Speed Downlink Packet Access
HSUPA	High-Speed Uplink Packet Access
ICMP	Internet Control Messages Protocol
IMEI	International Mobile Equipment Identity
IMEISV	International Mobile Equipment Identity and Software Version
MS	Mobile Station
NB-IoT	Narrow Band Internet of Thing

PDP	Packet Data Protocol
RRC	Radio Resource Control
RTC	Real Time Clock
SVN	Software Version Number
TA	Terminal Adapter
TCP	Transmission Control Protocol
TE	Terminal Equipment
TTL	Time To Live
UDP	User Datagram Protocol
UE	User Equipment
UICC	Universal Integrated Circuit Card
URC	Unsolicited Result Code
UUID	Universally Unique Identifier
